

**NEW**  
Heat Trace  
Shower  
with Halo  
pg  
55

# Emergency Fixtures

Drench Showers

Eye and Eye/Face Washes

Combination Drench Shower Eye and Eye/Face Washes

Enclosed Safety Showers

Tankless Tempering Systems

Navigator Skid Systems

Emergency Signaling Systems

Drench Hoses

Laboratory Fixtures

Emergency Thermostatic Mixing Valves

Portable Eyewashes



[BRADLEYCORP.COM](http://BRADLEYCORP.COM)



# Table of Contents

## What's New



Stainless Steel  
Fixtures with Halo

Pages 20, 25–26,  
28–29, 40–43

See Classic Model vs Halo Cross  
Reference on page 100 or on  
[bradleycorp.com](http://bradleycorp.com)



Halo® Heat Trace  
Shower and  
Eye/Face Wash  
Pages 46–48



Keltech® Tankless  
Skid Systems  
Pages 53



Emergency  
Signaling Systems  
Pages 56–58



Laboratory Eye &  
Eye/Face Washes  
with Halo  
Pages 68–71, 74, 75

New ANSI Quick Compliance Guide  
booklet available! Download at  
<http://bit.do/Bradley-ANSI-Guide>



## Standard Products

### Drench Showers

Freestanding	8
Quick Compliance Guide	9
Horizontal	11
Vertical	13

### Eye & Eye/Face Washes

Pedestal-mounted	15
Quick Compliance Guide	16
<i>S19214 Series Configurator</i>	22
Wall-mounted	23
<i>S19224 Series Configurator</i>	31

### Combination Drench Showers

Shower with Eyewash, Eye/Face Wash or Eye/Face Spray Ring	32
Quick Compliance Guide	33
<i>S19314 Series Configurator</i>	45
Heat Trace	46
<i>S19304 Series Configurator</i>	48

### Enclosed Safety Showers

Indoor and Outdoor Models	49
Quick Compliance Guide	51

### Keltech Tankless Heaters

Tankless Tempering Systems	52
----------------------------	----

### Emergency Thermostatic Mixing Valves

Thermostatic Mixing Valves	54
Navigator Skid Systems	55

### Emergency Signaling Systems

Signaling Systems	56
Flow Switches	59
<i>S19324 Series Configurator</i>	60
<i>S19324D1 Series Configurator</i>	61
<i>S19324D2 Series Configurator</i>	62

### Drench Hoses

Drench Hoses	63
Quick Compliance Guide	64
Deck-mounted	65
Wall-mounted	65
Back-flow Preventers	66

### Plumbed Laboratory Safety Solutions

Deck- and Wall-mounted Eye and Eye/Face Washes	67
Swing-activated Eye and Eye & Eye/Face Washes	69
Quick Compliance Guide	70

Recessed Drench Showers, Eye and Eye/Face Washes	73
---	----

### Portable Safety Solutions

On-Site® Portable Gravity-Fed Eyewashes	79
Quick Compliance Guide	80
Portable Pressurized Eyewashes	82

### Accessories

Portable Eyewash Accessories	84
Drench Hose Spray Kits	84
Privacy Curtain and Drench Shower Tester	84
Emergency Signaling Systems	85
Freeze and Scald Protection Valves	86
Retrofit Classic Dust Covers	91

### Replacement Parts: Spintec and Drench Showers

Handles	91
Retrofit Kits	92
Ball Valves	92
Hoses, Guide Brackets, Spray Valve	93
Back-flow Prevention	93

### Replacement Parts: Other

On-Site Water Eyewash Kit	94
On-Site Foam Liner	94
On-Site Gravity Fed Tank	94
Safety Signs	94
Safety Yellow Paint	94
Inspection Tag	94
Eyewash Test Gauge	94
Foot Treadle Kits	95
Adapters	95

### Standard Specifications 96

### Halo vs Classic Cross Reference 100

### Halo Certification Reference 102

### Numerical Index 106

## Barrier Free

### Drench Showers

#### Freestanding

S19-110BF	10
S19-110BFSS, S19-110BFSSZ	10

#### Horizontal Mounted

S19-120BF	13
S19-120ABF	13
S19-120SSBF, S19-120SSBFZ	13
S19-120FMBF	13

#### Vertical Mounted

S19-130BF	14
S19-130ABF	14



S19-130SSBF, S19-130SSBFZ	14
<b>Recess Mounted</b>	
S19-125BF	74
S19-125FMBF	74
S19-125SBF	74
S19-125SFMBF	74
<b>Eye &amp; Eye/Face Washes</b>	
<b>Pedestal Mounted</b>	
All Halo Models	17
S19214 Series Configurator	22
<b>Wall Mounted</b>	
All Halo Models	24
S19224 Series Configurator	31
<b>Swing Activated</b>	
S19274HDB	71
S19274HWB	71
S19-280D	71
S19-280W	71
S19274JDB	72
S19274JWB	72
S19-290D	72
S19-290W	72
<b>Cabinet Concealed, Swing Activated</b>	
S19284HB	75
S19284JB	75
S19294HB	76
S19294HBT	76
S19294JB	76
S19294JBT	76
<b>Combination Drench Shower and Eye &amp; Eye/Face Washes</b>	
S19314BFPB, S19314BFPBZ	39
S19314BFPBZS	39
S19314BF, S19314BFZ	39
S19314BFZS	40
S19314DCBF, S19314DCBFZ	41
S19314DCBFZS	41
S19314BFSS, S19314BFSSZ	42
S19314 Series Configurator	45
<b>Recessed, Swing Activated</b>	
S19345HXB	77
S19345HXBT	77
S19345HFB	77
S19345HFBT	77
S19345JXB	77
S19345JXBT	77
S19345JFB	77
S19345JFBT	77

## FROST PROOF

### Drench Showers (Through Wall)

S19-120HFP Series	12
-------------------	----

### Eye & Eye/Face Washes (Through Wall)

S19-220HFP Series	29
-------------------	----

### Combination Drench Shower and Eye & Eye/Face Washes

S19-310 Series	42
----------------	----

### Heat Trace

S19-304	46
---------	----

## Corrosion Resistant

### Drench Showers

#### Freestanding, Stainless Steel

S19-110SS, S19-110SSZ	10
S19-110BFSS, S19-110BFSSZ	10

#### Horizontal Mounted, Stainless Steel

S19-120SS, S19-120SSZ	12
S19-120SSBF, S19-120SSBFZ	13

#### Vertical Mounted, Stainless Steel

S19-130SS, S19-130SSZ	13
S19-130SSBF, S19-130SSBFZ	14

### Eye & Eye/Face Washes

#### Pedestal Mounted, Stainless Steel

S19214BSS, S19214BSSZ	20
S19214SC, S19214SCZ	20
S19214SS, S19214SSZ	20

#### Wall Mounted, Stainless Steel

S19224SC, S19224SCZ	29
S19224SS, S19224SSZ	29

#### Portable Pressurized, Stainless Steel

S19-690	83
S19-690LHS	83
S19-788	83
S19-788LHS	83

### Combination Drench Shower and Eye & Eye/Face Washes

#### Stainless Steel

S19314BFSS, S19314BFSSZ	42
S19314FSS, S19314FSSZ	42
S19314SC, S19314SCZ	42
S19314SS, S19314SSZ	43
S19314SS16, S19314SS16Z	43

### Shower Accessories

#### Foot Treadle Kits

S45-1314SS	95
S45-1314SS16	94

## BradEX®

### On-Site® Eyewash Kit

S19-949	81
---------	----

### Eyewashes

#### Freestanding

S19214EW	17
----------	----

#### Swing Activated

S19-270C	71
S19-270HD	71
S19-270HW	71
S19-270E	72

#### Laboratory

S19-200B	68
S19-270B	68

#### Gravity Fed

S19-921	81
---------	----

### Drench Showers

S19-120	12
S19-130	13

### Combination Drench Shower and Eye & Eye/Face Washes

S19314EW	34
S19314SBFW	37

### Emergency Thermostatic Mixing Valves

S19-2000	55
S19-2100	55
S19-2150	55
S19-2200	55
S19-2250	55
S19-2300	55
S19-2350	55

## Fast Shipping

Bradley's **BradEX®** shipping program allows you to prepare for upcoming inspections and respond to changing workplace needs. Fast replacements are just a phone call away and will ship within two days. The **BradEX®** shipping feature is available for a wide range of product, at no extra cost.



# Halo

EYE/FACEWASH

Halo™ surrounds you with the fastest, most effective relief in the industry. Bradley's new eye & eye/face wash provides the most washdown coverage for your face of any model on the market. In an emergency, your eyes and face can't afford to trust anything but the best in the industry.

- 1** Enhanced dust cover design in clear translucent yellow allowing for easy inspection. When the cover is opened, water flow starts automatically giving the user instant relief.
- 2** New ergonomic hand activation is easy to reach from any direction.
- 3** Separate supply waste and pipes to eye/face wash are industry first and exclusive to Bradley!
- 4** The Aquaduct™ design is the only selfdraining design for standard Eyewash models – another industry first and Bradley exclusive. The self-draining Aquaduct helps reduce the risk of bacteria growth when unit is not in use. Integral strainer inside the Aquaduct reduces debris in the water for additional eye protection and also prevents clogging.
- 5** New dust cover caps on the Eyewash are hinged for a more secure hold – keeping dust and debris off the water spouts.





# Spintec™


## SHOWERHEADS

SpinTec™ showerheads incorporate the latest technology in fluid dynamics and provide the most consistent distribution of water from a drench shower. That means the fastest, most effective removal of contaminants in the industry.

### SpinTec Standard Showerhead

Showerhead is constructed of ABS plastic so it is highly corrosion resistant.


- 1** Integral flow control provides a minimum of 20GPM (761 L/Min)
- 2** Contoured shape focuses water for faster washdown
- 3** Spinning motion of water creates optimal spray pattern



### SpinTec Uniform Distribution



### OLD Uneven Distribution



### SpinTec High Performance Stainless Steel

The 304 & 316 Stainless Steel showerhead provides the maximum corrosion resistance and durability for highly corrosive and abusive applications.



### Recessed Flush-Mounted SpinTec Showerhead

Provides the smallest footprint and clean appearance of in-ceiling mounting. Easy to install.



### SpinTec Showerhead with Stainless Steel Shroud

Provides new showerhead with a traditional looking shroud.






# Keltech

Electric Water Heaters

Tough enough for the most extreme environments on earth

On demand supply of ANSI-required tepid water for safety showers and eye/face washes – in seconds.

- No need to keep a 300 gal (1136 L) tank heated 24/7/365
- Easy to install – just add water and power. All you need is one electrical connection and a cold water line
- Under constant flow and pressure, temperatures stay within  $\pm 1^\circ\text{F}$  of set point
- Precision systems custom engineered to fit your application
- Meets ANSI/ISEA Z358.1 standards and third-party verified to UL/CSA standards
- Only electric tankless water heaters registered with the National Board and certified with the HLW stamp
- Optional features include NEMA 4X stainless steel enclosures, explosion proof purge system, and freeze protection to  $-20^\circ\text{F}$



For information contact your Bradley Representative or visit [bradleycorp.com](http://bradleycorp.com)



## Environmental and hazardous chemicals and site conditions



Within these industries warranting additional consideration are shown below. This list is not intended to be exhaustive, but rather, to serve as a starting point to begin the evaluation process of what types of hazards warrant the installation of a drench shower or Eyewash fixture that provides an ANSI-compliant 15-minute flush. Industries subject to a higher accident ratio and an increased rate of OSHA audits are:

- Healthcare
- Industrial
- Education
- Construction
- Agriculture
- Government
- Hospitality
- Retail
- Laboratories
- Food Processing
- Paper Mills
- Automotive
- Mining
- Trades
- Aerospace
- Ethanol/Oil Refineries
- Wastewater Treatment
- Utilities

## Common hazards that require a 15-minute flush

- Dust, dirt, salt, sand, cardboard, wood chips, powder, fine particulate
- Nails, wood splinters, staples
- Metal shavings, filings, dust, concrete, cement chips,
- Smoke, flammable or poisonous gases
- Insecticides, pesticides, herbicides, fumigants
- Solvents, stains, paint, thinner, acetone
- Bloodborne pathogens; blood, bodily fluids and remains
- Caustic water treatment chemicals
- Gas, diesel, cleaning solvents, antifreeze
- Laboratory chemicals, oxygen
- Bleach, chlorine, ammonia
- Battery acid, starter fluid, paints, oils, hydraulic fluid
- Bacteria, germs, biohazards
- Falling, flying or shifting debris, rocks, building materials and glass
- Thermal hazards, UV radiation burns (welder's flash), electrical arcs
- Acids, bases, solvents, lime
- Flammable liquids



## Important information about compliance

The U.S. Code of Federal Regulations 29CFR 1910.151 states: "Where the eyes or body of any person may be exposed to injurious corrosive materials, suitable facilities for quick drenching or flushing of the eyes and body shall be provided within the work area for immediate emergency use."


The American National Standards Institute (ANSI) establishes standards for minimum performance and use requirements for Eyewash and shower equipment.

The ANSI/ISEA Z358.1-2014 for Emergency Eyewash and Shower Equipment provides detailed guidelines to which OSHA, State OSHA and other regulatory agencies commonly refer.

The Joint Commission 2014 EC Standard for Hospitals requires: "The hospital takes action to minimize or eliminate identified safety and security risks in the physical environment." Furthermore, hospitals are required to "Minimize risk associated with selecting, handling, storing, transporting, using, and disposing hazardous chemicals." Surveyors commonly refer to OSHA requirements and the ANSI Standard for further guidance on best demonstrated practices.

Canadian Provincial authorities also typically refer to ANSI standards when auditing for or advising proper requirements for emergency Eyewash showers.





## S19-110 Series

### Overview

When there's the possibility of full-body chemical contamination, the first choice is an ANSI-compliant, full-body drench shower. Bradley drench showers, the S19-110 line of products, are a great choice when a wall-mounted drench shower isn't practical. And with the BradTect® corrosion-resistant yellow coating standard on most units, these drench showers are not only easy to see, but durable enough for your tough work environment.

### Key Features

- SpinTec showerhead improves water distribution
- Exceeds ANSI minimum water flow of 20 GPM (76 L/Min) at 30 psi (207 kPa)
- Stay-open ball valve with single-step activation
- Triangular stainless steel pull rod
- Universal ID sign
- BradTect corrosion-resistant yellow coating (except on stainless steel, PVC and chrome models)
- 1¼" (32 mm) NPT inlet
- One-year warranty
- Top- or mid-level supply standard on all drench showers and combination units
- ANSI/ISEA Z358.1 certified models available
- European EN 15154-1 certified models available
- AS/NZS4775:2007 & AS4020 certified models available

### Emergency Fixture Facts

Drench showers are required to have 16" (406 mm) of clearance around the fixture, from the center of the spray pattern. ANSI /ISEA Z358.1 Section 4.1.4

### Suggested Accessories

Standard and Explosion-Proof Signaling Systems	page 56-58
Drench Hose Spray Kits	page 84
Freeze and Scald Protection Valves	page 86

Other parts and accessories are listed beginning on page 84

### Recommended Emergency TMV

#### Navigator® EFX 25 (S19-2100)

The current ANSI standard calls for emergency Eyewashes and drench showers to deliver tepid water (60–100°F/15.5–37.7°C) for 15 minutes. A thermostatic mixing valve is needed to mix the hot and cold water supply. Bradley's Navigator® TMVs are the most reliable emergency TMVs on the market. One valve is required per plumbed unit.





# Quick Compliance Guide

This guide serves as a supplement to the ANSI/ISEA Z358.1-2014 standard.





## Safety Drench Showers

- Valve mechanism opens in one second or less; it stays open until manually closed. (Section 4.2) ①
- Supply with flushing fluid ("potable water, preserved water, preserved buffered saline solution or other medically acceptable solution..."). (Definitions, Sections 4.1.1, 4.4.1)
- Locate 10 seconds or 55' (16.8 m) from contaminants or hazardous materials. Locate on the same plane as hazard and free of obstructions. (Section 4.5.2, Appendix B5)
- Doors are an obstruction. (Appendix B5)
- Must resist corrosion in the presence of flushing fluid. (Section 4.1.5)
- Audible, visual and central control signal systems deter vandals and notify personnel that an accident occurred. (Appendix B4)
- Environmental conditions often require freeze or scald protection equipment. (Section 4.5.5)

## Top down view

Requires a 16" (406 mm) radius from the center of the drench shower spray pattern to be free of obstructions. (Section 4.1.4) ②



15-minute Flush	Tepid Water	Third-Party Certifications	Weekly Activations:	Annual Inspections
Compliant showers release a continuous flow of at least 20 GPM (76 L/Min) of tepid flushing fluid for a period of at least 15 minutes. (Sections 4.1.2, 4.4.1, 4.5.5, 4.5.6)	(lukewarm) 60–100°F (15.6–37.8°C) encourages full 15 minute flush or until medical personnel arrive. (Definitions, Sections 4.5.6, Appendix B6)	Manufacturers may have their safety fixtures independently evaluated by a third-party testing organization. Look for certification when selecting a compliant fixture. (Definitions)	Flush lines and test by activating weekly. Inspection tags are often included with fixtures to document testing and to satisfy a safety audit. (Section 4.6.2)	ANSI recommends a comprehensive annual inspection of the facility to evaluate modified work space, assess new hazards introduced into the area, and to identify fixtures needing replacement or repair. (Section 4.6.5)

FREE Confidential Safety Evaluation • 800.BRADLEY • [bradleysafety.com](http://bradleysafety.com)



Freestanding Drench Showers

**S19-110**

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic showerhead

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1

**S19-110SS**

Same features as S19-110, except is an all stainless steel fixture

Bradley's stainless steel emergency fixtures in 304 stainless recommended for harsh environments

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1

**S19-110SSZ**

Same features as S19-110SS except with BSPP thread

Certified to AS4775 and AS4020



S19-110



S19-110SS

Barrier-Free, Freestanding Drench Showers

**S19-110BF** 

Barrier-free design – fully accessible to people with physical disabilities

BradTect corrosion-resistant yellow coating


Plastic showerhead

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-110BF


**S19-110BFSS** 

Same features as S19-110BF, except is an all stainless steel fixture

Bradley's stainless steel emergency fixtures in 304 stainless recommended for harsh environments

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1

**S19-110BFSSZ** 

Same features as S19-110BFSS except with BSPP thread

Certified to AS4775 and AS4020

Please see Table of Contents for a complete listing of Bradley's barrier-free emergency products.





## S19-120 and S19-130 series

### Overview

A drench shower is required anywhere a MSDS sheet indicates that a full body flush may be required or where exposure to hazardous material is likely. Bradley's drench showers provide a complete full body deluge of water, to ensure that contaminants are rinsed from the body as rapidly and efficiently as possible. With water resources at a premium, Bradley's patented design features an integral 22 GPM (83 L/Min) flow restrictor that works in tandem with the showerhead flow pattern to ensure that the most effective ANSI 15-minute flush is achieved. Maximize your precious water resources by choosing Bradley.

### Key Features

- SpinTec showerhead improves water distribution
- Stainless steel pull rod with triangular handle
- Stay-open ball valve
- BradTest coated galvanized steel pipe
- Horizontal/vertical: 1" (25 mm) water supply
- Freestanding: 1 1/4" (32 mm) water supply
- ANSI/ISEA Z358.1 certified models available
- European EN 15154-1 certified models available
- AS/NZS4775:2007 & AS4020 certified models available
- One-year warranty

### Emergency Fixture Facts

Bradley equips all ANSI-compliant emergency fixtures with a valve that will stay open until manually closed, allowing the user free use of their hands during an emergency. ANSI/ISEA Z358.1 Section 4.2

### Suggested Accessories

Standard and Explosion-Proof Signaling Systems	page 56–58
Drench Hose Spray Kits	page 84
Freeze and Scald Protection Valves	page 86

Other parts and accessories are listed beginning on page 84

### Recommended Emergency TMV

#### Navigator EFX 25 (S19-2100)

The current ANSI standard calls for emergency Eyewashes and drench showers to deliver tepid water (60–100°F/15.5–37.7°C) for 15 minutes. A thermostatic mixing valve is needed to mix the hot and cold water supply. Bradley's Navigator TMVs are the most reliable emergency TMVs on the market. One valve is required per plumbed unit.





## Horizontal Drench Showers

### S19-120

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Impact-resistant plastic showerhead

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-120

### S19-120A

Same features as S19-120, except with stainless steel shroud

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-120A

### S19-120SS

Same features as S19-120, except is an all stainless steel fixture

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-120SS

### S19-120SSZ

Same features as S19-120SS except with BSPP thread

Certified to AS4775 and AS4020

## Cord-Operated Horizontal Drench Showers

### S19-120G

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Impact-resistant plastic showerhead

Includes self-closing ball valve

Does not comply with ANSI/ISEA Z358.1



S19-120G

## Frost Proof Horizontal Drench Showers

### S19-120HFP



Galvanized steel protected with BradTect corrosion-resistant yellow coating

Impact-resistant plastic showerhead

Available in three wall thicknesses:

S19-120HFP8 0–8" (0–203 mm)

S19-120HFP12 8–12" (203–305 mm) – standard

S19-120HFP18 12–18" (305–457 mm)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-120HFP

## Horizontal Drench Shower with Hose Spray

### S19-120P

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Impact-resistant plastic showerhead

Includes 8' (2.4 m) drench hose for body rinse

Easily wall mounted

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-120P

## Chrome-Plated Brass Horizontal Drench Shower

### S19-120T

Chrome-plated, brass pipe and fittings for bright, mirror finish

Impact-resistant stainless steel shroud

Easily wall mounted

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-120T



## Flush-Mounted Horizontal Drench Shower

### S19-120FM

Integral flange mounts flush with ceiling

Concealed pipe and fittings

Galvanized steel protected with BradTect corrosion-resistant yellow coating

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-120FM

## Barrier-Free, Flush-Mounted Horizontal Drench Shower

### S19-120FMBF



Integral flange mounts flush with ceiling

Concealed pipe and fittings

Galvanized steel protected with BradTect corrosion-resistant yellow coating

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1

## Barrier-Free Horizontal Drench Showers

### S19-120BF



Galvanized steel protected with BradTect corrosion-resistant yellow coating

Impact-resistant plastic showerhead

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-120BF

### S19-120ABF



Same features as S19-120BF, except with stainless steel shroud

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-120ABF

### S19-120SSBF



Same features as S19-120BF, except is an all stainless steel fixture

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1

### S19-120SSBFZ



Same features as S19-120SSBF except with BSPP thread

Certified to AS4775 and AS4020


## Vertical Drench Showers

### S19-130

Impact-resistant plastic showerhead

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-130

### S19-130A

Same features as S19-130, except with stainless steel shroud

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-130A

### S19-130SS

Same features as S19-130, except is an all stainless steel fixture

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-130SS

### S19-130SSZ

Same features as S19-130SS, except with BSPP thread

Certified to AS4775 and AS4020



# Vertical Drench Showers

## Cord-Operated Vertical Drench Showers

### S19-130F

Impact-resistant plastic showerhead

Includes self-closing ball valve

Self-closing valve does not comply with ANSI/ISEA Z358.1



S19-130F


## Flow Controls

In the interest of water conservation, each shower head features an integral 20 GPM (76 L/Min) flow control. This item must be purchased separately for most competing brands.



## Frost Proof

Bradley features frost-proof emergency fixtures for when an adjacent outside wall of a heated building is available. They can also be free standing with a buried supply pipe. See your local plumbing codes for code compliance.



## Barrier Free

Halo models are barrier-free. This provides ease of use for individuals with disabilities.



## Barrier-Free Vertical Drench Showers

### S19-130BF



Impact-resistant plastic showerhead

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-130BF

### S19-130ABF



Same features as S19-130BF, except with stainless steel showerhead

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1

### S19-130SSBF



Same features as S19-130ABF, except is an all stainless steel fixture

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1

### S19-130SSBFZ



Same features as S19-130SSBF except with BSPP thread

Certified to AS4775 and AS4020





## S19214 Series

### Overview

Safety and maintenance personnel often select pedestal-mounted Eyewashes where a wall-mounted fixture is not practical due to site conditions. As a leading manufacturer of emergency fixtures, Bradley provides a variety of Eyewash solutions; barrier-free, frost-proof or stainless steel fixtures with a variety of different spray patterns. Committed to providing a strong value proposition, Bradley also offers complimentary safety inspections to facilities, providing expert advice about emergency fixture solutions.

### Key Features

- Halo Eyewashes and eye/face washes provide the most washdown coverage available
- Exceed ANSI-mandated flow rates
- Universal activation
- BradTest coated galvanized steel pipe
- ½" (13 mm) water supply, 1¼" (32 mm) waste
- All pedestal-mounted units with Halo meet barrier-free requirements
- One-year warranty
- ANSI/ISEA Z358.1 certified models available
- European EN 15154-2 certified models available
- AS/NZS4775:2007 & AS4020 certified models available

### Emergency Fixture Facts

The emergency fixture must provide a continuous flow of flushing fluid. ANSI/ISEA Z358.1 Section 5.4.5, 6.4.5

### Suggested Accessories

Standard and Explosion-Proof Signaling Systems	page 56–58
Drench Hose Spray Kits	page 84
Freeze and Scald Protection Valves	page 86
Retrofit Dust Cover Kits	page 88, 90–91
Foot Treadle Kits	page 95

Other parts and accessories are listed beginning on page 84

### Recommended Emergency TMV

#### Navigator EFX 8 (S19-2000)

The current ANSI standard calls for emergency Eyewashes and drench showers to deliver tepid water (60–100°F/15.5–37.7°C) for 15 minutes. A thermostatic mixing valve is needed to mix the hot and cold water supply. Bradley's Navigator TMVs are the most reliable emergency TMVs on the market. One valve is required per plumbed unit.



Don't see the product you are looking for? Go to page 22 to use the S19214 Configurator




# Quick Compliance Guide

This guide serves as a supplement to the ANSI/ISEA Z358.1-2014 standard.



## Eye and Eye/Face Wash Fixtures


- Valve mechanism opens in one second or less; it stays open until manually closed. (Sections 5.2, 6.2) **1**
- Supply with flushing fluid, ("potable water, preserved water, preserved buffered saline solution or other medically acceptable solution...") Definitions, Sections 5.1.1, 6.1.1)
- Locate 10 seconds or 55' (16.8 m) from contaminants or hazardous materials. Locate on the same plane as hazard and free of obstructions. (Sections 5.4.2, 6.4.2, Appendix B5)
- Must resist corrosion in the presence of flushing fluid. (Sections 5.1.5, 6.1.5) **2**
- Protect eye and eye/face wash heads from contaminants. (Sections 5.1.3, 6.1.3)
- Flow Rates: **Eyewash** unit delivers a minimum of .4 GPM (1.5 L/Min) for 15 minutes. (Section 5.1.6) **Eye/face wash** unit delivers a minimum of 3.0 GPM (11 L/Min) for 15 minutes. (Section 6.1.6)
- Use a flow meter to test flow rate; use a test gauge to test flow pattern. (Sections 5.1.8, 5.3.1, 6.1.7, 6.1.8, 6.3, 6.3.1)
- Audible, visual and central control signal systems deter vandalism and alert safety personnel. (Appendix B4)
- Environmental conditions often require freeze or scald protection equipment. (Sections 5.4.5, 6.4.5)



## Top down view

Required to be free of obstructions a minimum of 6" (152 mm) from the outside of the eye or eye/face wash sprayheads. (Sections 5.4.4, 6.4.4) **3**

Use a Bradley test gauge (Model 269-1444) to check flow pattern. **4**



15-minute Flush	Tepid Water	Third-Party Certifications	Weekly Activations:	Annual Inspections
Compliant fixtures release a continuous flow of tepid flushing fluid for a minimum of 15 minutes. (Sections 5.1.6, 5.4.5, 5.4.6, 6.1.6, 6.4.5, 6.4.6)	(lukewarm) 60–100°F (15.6–37.8°C) encourages full 15 minute flush or until medical personnel arrive. (Definitions, Sections 5.4.6, 6.4.6, Appendix B6)	Manufacturers may have their safety fixtures independently evaluated by a third-party testing organization. Look for certification when selecting a compliant fixture. (Definitions)	Flush lines and test by activating weekly. Inspection tags are often included with fixtures to document testing and to satisfy a safety audit. (Sections 5.5.2, 6.5.2)	ANSI recommends a comprehensive annual inspection of the facility to evaluate modified work space, assess new hazards introduced into the area, and to identify fixtures needing replacement or repair. (Sections 5.5.2, 5.5.5, 6.5.2, 6.5.5)

**FREE Confidential Safety Evaluation • 800.BRADLEY • bradleysafety.com**



## Pedestal-Mounted Eyewashes

### S19214EW

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19214EW

### S19214BZS

All stainless steel piping

Stainless steel bowl

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2



S19214BZS

### S19214EWZ

Same features as S19214EW except with BSPP thread

Listed by Intertek to EN 15154-2

### S19214EWZS

All stainless steel piping

Plastic bowl

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2



S19214EWZS

## Pedestal-Mounted Eyewashes with Hinged Dust Cover

### S19214PDC

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic bowl and dust cover

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19214PDC

### S19214PDCZ

Same features as S19214PDC except with BSPP thread

Listed by Intertek to EN 15154-2



S19214B

### S19214B

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2

### S19214PDCZS

All stainless steel piping

Plastic bowl and dust cover

BSPP thread

Listed by Intertek to EN 15154-2

Certified to AS4775 and AS4020



S19214PDCZS

### S19214BZ

Same features as S19214B except with BSPP thread

Listed by Intertek to EN 15154-2



## Pedestal-Mounted Eyewashes and Eye/Face Washes

### S19214DC

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl and dust cover

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19214DC

### S19214FWZS

All stainless steel piping

Plastic bowl

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2



S19214FWZS

### S19214DCZ

Same features as S19214DC except with BSPP thread

Listed by Intertek to EN 15154-2



S19214DCZS

### S19214Y

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19214Y

### S19214DCZS

All stainless steel piping

Stainless steel bowl and dust cover

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2

### S19214YZ

Same features as S19214Y except with BSPP thread

Listed by Intertek to EN 15154-2



S19214YZS

## Pedestal-Mounted Eye/Face Washes

### S19214FW

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19214FW

### S19214YZS

All stainless steel piping

Stainless steel bowl

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2



S19214YF

### S19214FWZ

Same features as S19214FW except with BSPP thread

Listed by Intertek to EN 15154-2

### S19214YF

Hand or foot operation

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



## S19214YFZ

Same features as S19214YF except with BSPP thread

Listed by Intertek to EN 15154-2

## S19214YFZS

Hand or foot operation

All stainless steel piping

Stainless steel bowl

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2



S19214YFZS

## Pedestal-Mounted Eyewashes with Hinged Dust Cover

### S19214PDCFW

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic bowl and dust cover

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19214PDCFW

### S19214PDCFWZ

Same features as S19214PDCFW except with BSPP thread

Listed by Intertek to EN 15154-2

### S19214PDCFWZS

All stainless steel piping

Plastic bowl and dust cover

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2



S19214PDCFWZS

### S19214DCFW

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl and dust cover

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19214DCFW

### S19214DCFWZ

Same features as S19214DCFW except with BSPP thread

Listed by Intertek to EN 15154-2

## Pedestal-Mounted Eye/Face Wash with Hose Spray

### S19214P

8' (2.4 m) hand-held drench hose attachment for body rinse

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19214P

### S19214PZ

Same features as S19214P except with BSPP thread

Listed by Intertek to EN 15154-2

AS4775 & AS4020 certified



## Pedestal-Mounted Eyewashes and Eye/Face Washes

### S19214DCFWZS

- All stainless steel piping
- Stainless steel bowl and dust cover
- BSPP thread
- Certified to AS4775 and AS4020
- Listed by Intertek to EN 15154-2



S19214DCFWZS

### S19214SS

- All stainless steel fixture
- Hand or foot operation
- UL classified to meet ANSI/ISEA Z358.1
- Listed by Intertek to EN 15154-2



S19214SS

## All Stainless Steel Pedestal-Mounted Eye/Face Washes

### S19214BSS

- All stainless steel fixture
- UL classified to meet ANSI/ISEA Z358.1
- Listed by Intertek to EN 15154-2



S19214BSS

### S19214BSSZ

- Same features as S19214BSS except with BSPP thread
- Listed by Intertek to EN 15154-2
- Certified to AS4775 and AS4020
- Listed by Intertek to EN 15154-2

### S19214SC

- All stainless steel fixture
- Hinged dust cover
- UL classified to meet ANSI/ISEA Z358.1
- Listed by Intertek to EN 15154-2



S19214SC

### S19214SCZ

- Same features as S19214SC except with BSPP thread
- Listed by Intertek to EN 15154-2





### Eyewashes

When the safety risk targets the eye area, Bradley's Eyewashes are the recommended solution for emergency care. The Eyewash sprayheads flow at approximately 5.1 GPM (19 L/Min), exceeding ANSI's 0.4 GPM (1.5 L/Min) flow rate. The flow gently flushes water directly on the eye to wash out contaminants.



### Eye/Face Washes

When chemicals and other hazardous liquids can contaminate the face and eyes, an eye/face wash is the solution. Bradley's eye/face wash heads feature integral flow controls that provide a soft flush of approximately 5.1 GPM (19 L/Min). Eye/face washes are considered premium fixtures that exceed ANSI's 3.0 GPM (11 L/Min) mandate.



### Dust Covers

The most effective way to keep the unit clean and functioning properly is to have a dust cover over the eye or eye/face wash. See-through plastic dust covers provide effective dust protection, but also allow for easy inspection. These covers automatically open when the eye or eye/face wash is activated. Dust covers are available as standard equipment on many eye and eye/face washes, or can be ordered as a retrofit kit.



### Foot Treadle

Foot treadles provide hands-free activation for eye and eye/face washes. Foot treadles are available as standard equipment on some eye and eye/face washes, or can be ordered as a retrofit kit.



# S19214 Series Configurator


Don't see a model that meets your application? Use the selections below to build one to suit your needs. Select one option from each category. Fill in the squares below with the corresponding option letter or number. Use the resulting alphanumeric number to specify the model and configuration for your desired product.

## 1 Configuration



- B** 24 in (61 cm) Drain Height
- O** 6 in (15.2 cm) Drain Height, Standard

## 2 Pipe Material



- A** NPT <sup>†</sup>, Yellow BradText Galvanized Steel, 1.25 in (32 mm)
- B** NPT <sup>†</sup>, All 304 Stainless Steel, 1.25 in (32 mm)
- C** NPT <sup>†</sup>, All 316 Stainless Steel, 1.25 in (32 mm)
- D** NPT <sup>†</sup>, Chrome-Plated, 1.25 in (32 mm)
- F** BSPP <sup>°</sup>, Yellow BradText Galvanized Steel, 1.25 in (32 mm)
- G** BSPP <sup>°</sup>, All 304 Stainless Steel, 1.25 in (32 mm)
- H** BSPP <sup>°</sup>, All 316 Stainless Steel, 1.25 in (32 mm)
- J** BSPP <sup>°</sup>, Chrome-Plated, 1.25 in (32 mm)

## 3 Ball Valve



- 1** Stay-Open Eyewash, Chrome-Plated Brass
- 2** Stay-Open Eyewash, 316 SS

## 4 Eyewash or Eye/Face Wash



- A** Halo Eyewash
- B** Halo Eye/Face Wash
- D** Halo Eyewash, 304 SS Yoke
- E** Halo Eye/Face Wash, 304 SS Yoke
- F** Halo 304 Stainless Eye/Face Wash, 304 SS Yoke\*\*
- G** Halo Eyewash, 316 SS Yoke
- H** Halo Eye/Face Wash, 316 SS Yoke
- J** Halo 316 Stainless Eye/Face Wash, 316 SS Yoke\*\*

## 5 Bowl and Dust Cover




- A** Plastic Bowl, No Dust Cover
- B** Plastic Bowl, Plastic Dust Cover
- D** 304 SS, No Dust Cover
- E** 304 SS, 304 SS Dust Cover
- F** 304 SS, Plastic Dust Cover
- G** 316 SS, No Dust Cover
- H** 316 SS, 316 SS Dust Cover
- J** 316 SS, Plastic Dust Cover
- O** No Bowl or Dust Cover

## 6 Activation



- A** 300 SS Handle
- B** 316 SS Handle
- C** 300 SS Handle with 300 SS Foot Pedal \*
- D** 300 SS Handle with 316 SS Foot Pedal \*
- E** 316 SS Handle with 316 SS Foot Pedal \*

## 7 Drench Hose and Back-flowPrevention



- A** Drench Hose Kit with Vacuum Breaker
- B** Drench Hose Kit with N9 Back-flowPreventer
- C** Drench Hose Kit with 9D Back-flowPreventer
- D** Drench Hose Kit without Back-flowPreventer
- O** No Drench Hose and No Back-flowPrevention

## 8 Freeze and Scald Protection



- N** Anti-Freeze Valve
- P** Anti-Scald Valve
- R** Anti-Freeze and Anti-Scald Valves
- O** No Anti-Freeze Valve and No Anti-Scald Valve
- Z** Anti-Freeze and Anti-Scald Valve Ready

► NPT (National Pipe Thread).

◊ BSPP (British Standard Pipe Parallel Threads)

\* Not available with barrier-free configurations.

\*\*Must select stainless steel pipe and ball valve when stainless steel eye/face wash is required.

Fill in 1 through 8 to specify the Halo model and configuration for your desired project:

						<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>
S	1	9	2	1	4								





## S19224 series

### Overview

Wall-mounted emergency units are classic fixtures that originated from safety's early days. The classic fixture evolved from a basic Eyewash model with little to no options, to the fixtures of today with standard high visibility, yellow corrosion-resistant coating, plastic and stainless steel dust covers, various flow rates and flow patterns to flush the most elusive contaminants from the face. Wall-mounted fixtures are among the most compact, versatile safety solutions on the market. They can be found in industrial facilities, airports, auto repair shops, food processing environments and paper mills to name a few.

### Key Features

- Halo Eyewashes and eye/face washes provide the most washdown coverage available
- Dust cover protects fixture from dust and debris
- Fixtures exceed ANSI-mandated flow rates
- Single-step activation
- BradTect corrosion-resistant yellow coating
- Wall-mounted units with Halo meet barrier-free requirements
- ANSI/ISEA Z358.1 certified models available
- European EN 15154-2 certified models available
- AS/NZS4775:2007 & AS4020 certified models available
- One-year warranty

### Emergency Fixture Facts

An ANSI-compliant Eyewash provides 15-minutes of flushing fluid.  
ANSI/ISEA Z358.1 Section 5.1.6, 6.1.6

### Suggested Accessories

Standard and Explosion-Proof Signaling Systems	page 56–58
Drench Hose Spray Kits	page 84
Freeze and Scald Protection Valves	page 86
Retrofit Dust Cover Kits	page 88, 90–91
Foot Treadle Kits	page 95

Other parts and accessories are listed beginning on page 84

### Recommended Emergency TMV

#### Navigator EFX 8 (S19-2000)

The current ANSI standard calls for emergency Eyewashes and drench showers to deliver tepid water (60–100°F/15.5–37.7°C) for 15 minutes. A thermostatic mixing valve is needed to mix the hot and cold water supply. Bradley's Navigator TMVs are the most reliable emergency TMVs on the market. One valve is required per plumbed unit.



Don't see the product you are looking for? Go to page 31 to use the S19224 Configurator



# Wall-Mounted Eyewashes and Eye/Face Washes

## Wall-Mounted Eyewashes

### S19224EW

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224EW

### S19224BZS

All stainless steel piping

Stainless steel bowl

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2



S19224BZS

### S19224EWZ

Same features as S19224EW except with BSPP thread

Listed by Intertek to EN 15154-2



S19224EWZS

### S19224EWZS

All stainless steel piping

Plastic bowl

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2



S19224EWZS

### S19224PT

Tailpiece and P-trap

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224PT

### S19224PTZ

Same features as S19224PT except with BSPP thread

Listed by Intertek to EN 15154-2



S19224PTZ

### S19224B

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224B

### S19224PTZS

Tailpiece and P-trap

All stainless steel piping

Plastic bowl

BSPP thread

Listed by Intertek to EN 15154-2



S19224PTZS

### S19224BZ

Same features as S19224B except with BSPP thread

Listed by Intertek to EN 15154-2



### S19224BPT

Tailpiece and P-trap

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224BPT

### S19224BPTZ

Same features as S19224BPT except with BSPP thread

Listed by Intertek to EN 15154-2

### S19224BPTZS

Tailpiece and P-trap

All stainless steel piping

Stainless steel bowl

BSPP thread

Listed by Intertek to EN 15154-2



S19224BPTZS

### S19224PDCZ

Same features as S19224PDC except with BSPP thread

Listed by Intertek to EN 15154-2

### S19224PDCZS

All stainless steel piping

Plastic bowl and dust cover

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2



S19224PDCZS

### S19224DC

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl and dust cover

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224DC

### S19224DCZ

Same features as S19224DC except with BSPP thread

Listed by Intertek to EN 15154-2

### S19224DCZS

All stainless steel piping

Stainless steel bowl and dust cover

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2



S19224DCZS

## Wall-Mounted Eyewashes with Hinged Dust Cover

### S19224PDC

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic bowl and dust cover

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224PDC



## Wall-Mounted Eyewashes and Eye/Face Washes

### S19224DCPT

Tailpiece and P-trap

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl and dust cover

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224DCPT

### S19224FWZS

All stainless steel piping

Plastic bowl

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2



S19224FWZS

### S19224DCPTZ

Same features as S19224DCPT except with BSPP thread

Listed by Intertek to EN 15154-2

### S19224FWPT

Tailpiece and P-trap

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224FWPT

### S19224DCPTZS

Tailpiece and P-trap

All stainless steel piping

Stainless steel bowl and dust cover

BSPP thread

Listed by Intertek to EN 15154-2



S19224DCPTZS

### S19224FWPTZ

Same features as S19224FWPT except with BSPP thread

Listed by Intertek to EN 15154-2

## Wall-Mounted Eye/Face washes

### S19224FW

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224FW

### S19224FWPTZS

Tailpiece and P-trap

All stainless steel piping

Plastic bowl

BSPP thread

Listed by Intertek to EN 15154-2



S19224FWPTZS

### S19224FWZ

Same features as S19224FW except with BSPP thread

Listed by Intertek to EN 15154-2

### S19224T

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224T



## S19224TZ

Same features as S19224T except with BSPP thread

Listed by Intertek to EN 15154-2

## S19224TZS

All stainless steel piping

Stainless steel bowl

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2



S19224TZS

## S19224TPTZ

Same features as S19224TPT except with BSPP thread

Listed by Intertek to EN 15154-2

## S19224TPTZS

Tailpiece and P-trap

All stainless steel piping

Stainless steel bowl

BSPP thread

Listed by Intertek to EN 15154-2



S19224TPTZS

## S19224P

8' (2.4 m) hand-held drench hose for body rinse

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224P

## S19224Y

Hand or foot operation

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2

Unit is not Barrier-Free



S19224Y

## S19224PZ

Same features as S19224P except with BSPP thread

Listed by Intertek to EN 15154-2

## S19224TPT

Tailpiece and P-trap

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224TPT

## S19224YZ

Same features as S19224Y except with BSPP thread

Listed by Intertek to EN 15154-2

Unit is not Barrier-Free



## Wall-Mounted Eyewashes and Eye/Face Washes

### S19224YZS

- Hand or foot operation
- All stainless steel piping
- Stainless steel bowl
- BSPP thread
- Certified to AS4775 and AS4020
- Listed by Intertek to EN 15154-2
- Unit is not Barrier-Free



S19224YZS

### S19224DCFW

- Galvanized steel protected with BradTect corrosion-resistant yellow coating
- Stainless steel bowl and dust cover
- UL classified to meet ANSI/ISEA Z358.1
- Listed by Intertek to EN 15154-2



S19224DCFW

### S19224DCFWZ

- Same features as S19224DCFW except with BSPP thread
- Listed by Intertek to EN 15154-2

## Wall-Mounted Eye/face Washes with Hinged Dust Cover

### S19224PDCFW

- Galvanized steel protected with BradTect corrosion-resistant yellow coating
- Plastic bowl and dust cover
- UL classified to meet ANSI/ISEA Z358.1
- Listed by Intertek to EN 15154-2



S19224PDCFW

### S19224DCFWZS

- All stainless steel piping
- Stainless steel bowl and dust cover
- BSPP thread
- Certified to AS4775 and AS4020
- Listed by Intertek to EN 15154-2



S19224DCFWZS

### S19224PDCFWZ

- Same features as S19224PDCFW except with BSPP thread
- Listed by Intertek to EN 15154-2

### S19224DCRPT

- Tailpiece and P-trap
- Galvanized steel protected with BradTect corrosion-resistant yellow coating
- Stainless steel bowl and dust cover
- UL classified to meet ANSI/ISEA Z358.1
- Listed by Intertek to EN 15154-2



S19224DCRPT

### S19224PDCFWZS

- All stainless steel piping
- Plastic bowl and dust cover
- BSPP thread
- Certified to AS4775 and AS4020
- Listed by Intertek to EN 15154-2



S19224PDCFWZS

### S19224DCRPTZ

- Same features as S19224DCRPT except with BSPP thread
- Listed by Intertek to EN 15154-2



## S19224DCRPTZS

Tailpiece and P-trap

All stainless steel piping

Stainless steel bowl and dust cover

BSPP thread

Listed by Intertek to EN 15154-2



S19224DCRPTZS

## All Stainless Steel Eyewashes and Eye/Face Washes

### S19224SC

All stainless steel fixture

Hinged dust cover

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224SC

### S19224SCZ

Same features as S19224SC except with BSPP thread

Listed by Intertek to EN 15154-2

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2

### S19224SS

All stainless steel fixture

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-2



S19224SS

### S19224SSZ

Same features as S19224SS except with BSPP thread

Listed by Intertek to EN 15154-2

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-2

## Barrier-Free, Wall-Mounted Eye/Face Wash with Wrap-Around Skirt

### S19-220BF



Stainless steel wrap-around skirt and eyewash bowl

Features chrome-plated circular spray ring for full face spray

UL classified to meet ANSI/ISEA Z358.1



S19-220BF

## Frost-Proof, Wall-Mounted Eyewash

### S19-220HFP



Galvanized steel protected with BradTect corrosion-resistant yellow coating

Stainless steel bowl

Available in three wall thicknesses:

S19-220HFP8 0-8" (0-203 mm)

S19-220HFP12 8-12" (203-305 mm) – standard


S19-220HFP18 12-18" (305-457 mm)

UL classified to meet ANSI/ISEA Z358.1



S19-220HFP






### Eye and Eye/Face Wash Bowls

Bradley's eye and eye/face wash bowls come in two different materials – plastic and stainless steel. The high-visibility plastic bowls are intended for general use. The impact-resistant plastic will stand up to regular wear and tear. For the most durable bowl, select stainless steel bowls for rugged environments, where impact and corrosion could be a problem.

### Dust Covers

The most effective way to keep the unit clean and functioning properly is to have a dust cover over the eye or eye/face wash. See-through plastic dust covers provide effective dust protection, but also allow for easy inspection. These covers automatically open when the eye or eye/face wash is activated. Dust covers are available as standard equipment on many eye and eye/face washes, or can be ordered as a retrofit kit.



### Frost Proof

Bradley features frost-proof emergency fixtures for when an adjacent outside wall of a heated building is available. They can also be free standing with a buried supply pipe. See your local plumbing codes for code compliance.



### Barrier Free

Halo models are barrier-free. This provides ease of use for individuals with disabilities.



# S19224 Series Configurator


Don't see a model that meets your application? Use the selections below to build one to suit your needs. Select one option from each category. Fill in the squares below with the corresponding option letter or number. Use the resulting alphanumeric number to specify the model and configuration for your desired product.

1 Configuration



- O Standard Wall Mount

2 Pipe Material



- A NPT ▶, Yellow BradTect Galvanized Steel, 1.25 in (32 mm)
- B NPT ▶, All 304 Stainless Steel, 1.25 in (32 mm)
- C NPT ▶, All 316 Stainless Steel,\* 1.25 in (32 mm)
- D NPT ▶, Chrome-Plated, 1.25 in (32 mm)
- F BSPP ◊, Yellow BradTect Galvanized Steel, 1.25 in (32 mm)
- G BSPP ◊, All 304 Stainless Steel, 1.25 in (32 mm)
- H BSPP ◊, All 316 Stainless Steel,\* 1.25 in (32 mm)
- J BSPP ◊, Chrome-Plated, 1.25 in (32 mm)

3 Ball Valve



- 1 Stay-Open Eyewash, Chrome-Plated Brass
- 2 Stay-Open Eyewash, 316 SS

4 Eyewash or Eye/Face Wash



- A Halo Eyewash
- B Halo Eye/Face Wash
- D Halo Eyewash, 304 SS Yoke
- E Halo Eye/Face Wash, 304 SS Yoke
- F Halo 304 Stainless Eye/Face Wash, 304 SS Yoke \*\*
- G Halo Eyewash, 316 SS Yoke
- H Halo Eye/Face Wash, 316 SS Yoke
- J Halo 316 Stainless Eye/Face Wash, 316 SS Yoke \*\*

5 Bowl and Dust Cover



- A Plastic Bowl, No Dust Cover
- B Plastic Bowl, Plastic Dust Cover
- D 304 SS, No Dust Cover
- E 304 SS, 304 SS Dust Cover
- F 304 SS, Plastic Dust Cover
- G 316 SS, No Dust Cover
- H 316 SS, 316 SS Dust Cover
- J 316 SS, Plastic Dust Cover
- O No Bowl or Dust Cover

6 Activation



- A 300 SS Handle
- B 316 SS Handle
- D 300 SS Handle with 300 SS Foot Pedal \*

7 Waste



- A Tail-piece
- D P-trap
- O No Waste

8 Drench Hose and Back-flow Prevention



- A Drench Hose Kit with Vacuum Breaker
- B Drench Hose Kit with N9 Back-flow Preventer
- C Drench Hose Kit with 9D Back-flow Preventer
- D Drench Hose Kit without Back-flow Preventer
- O No Drench Hose and No Back-flow Prevention

9 Freeze and Scald Protection



- N Anti-Freeze Valve
- P Anti-Scald Valve
- R Anti-Freeze and Anti-Scald Valves
- O No Anti-Freeze Valve and No Anti-Scald Valve
- Z Anti-Freeze and Anti-Scald Valve Ready

▶ NPT (National Pipe Thread).  
◊ BSPP (British Standard Pipe Parallel Threads)  
\* Not available with barrier-free configurations.  
\*\*Must select stainless steel pipe and ball valve when stainless steel eye/face wash is required.

Fill in 1 through 8 to specify the Halo model and configuration for your desired project:

	1	2	3	4	5	6	7	8
S	1	9	2	2	4			





# S19314 Series

## Overview

Bradley's S19314 Series is the most complete safety fixture on the market. The drench shower provides full-body relief from contamination, and the eye or eye/face wash targets those areas of the body where a gentle spray of water is optimal.

## Key Features

- Halo Eyewashes and eye/face washes provide the most washdown coverage available
- SpinTec showerhead improves water distribution
- Stay-open ball valve with single-step activation
- Triangular stainless steel pull rod
- BradTest corrosion-resistant yellow coating (except on stainless steel, PVC and chrome models)
- Frost-proof and barrier-free models available
- Universal ID sign
- Top- or mid-level supply standard on all drench showers and combination units
- Integrated eye or eye/face wash with capped Eyewash heads
- One-year warranty
- 1¼" (32 mm) NPT inlet
- Single-step eye or eye/face wash activation
- Single-step drench shower activation
- ANSI/ISEA Z358.1 certified models available
- European EN 15154-1 and EN 15154-2 certified models available
- AS/NZS4775:2007 & AS4020 certified models available

## Emergency Fixture Facts

Locate safety fixtures 10 seconds or 55' (16.8 m) from a hazardous area. ANSI/ISEA Z358.1 Section 7.4.2, Appendix B5

## Suggested Accessories

Standard and Explosion-Proof Signaling Systems	page 56–58
Drench Hose Spray Kits	page 84
Freeze and Scald Protection Valves	page 86
Retrofit Dust Cover Kits	page 88, 90–91
Foot Treadle Kits	page 95

Other parts and accessories are listed beginning on page 84

## Recommended Emergency TMV

### Navigator EFX 25 (S19–2100)

The current ANSI standard calls for emergency Eyewashes and drench showers to deliver tepid water (60–100°F/ 15.5–37.7°C) for 15 minutes. A thermostatic mixing valve is needed to mix the hot and cold water supply. Bradley's Navigator TMVs are the most reliable emergency TMVs on the market. One valve is required per plumbed unit.



Don't see the product you are looking for? Go to page 45 to use the S19314 Configurator



# Quick Compliance Guide

This guide serves as a supplement to the ANSI/ISEA Z358.1-2014 standard.

## Combination Drench Shower, Eye and Eye/Face Washes



- Valve mechanism opens in one second or less; it stays open until manually closed. (Sections 4.2, 5.2, 6.2, 7.1.1, 7.1.2, 7.1.3) **1**
- Drench shower and eye or eye/face wash must operate simultaneously. (Section 7.4.4)
- Supply with flushing fluid ("potable water, preserved water, preserved buffered saline solution or other medically acceptable solution..."). (Definitions, Sections 4.1.1, 4.4.1, 5.1.1, 6.1.1, 7.1.2, 7.1.3)
- Locate 10 seconds or 55' (16.8 m) from contaminants or hazardous materials. Locate on same plane as the hazard, free of obstructions. (Sections 4.5.2, 5.4.2, 6.4.2, 7.1.1, 7.1.2, 7.1.3, 7.4.2, Appendix B5) **2**
- Must resist corrosion in the presence of flushing fluid (Sections 4.1.5, 5.1.5, 6.1.5, 7.1.1, 7.1.2, 7.1.3)
- Protect eye and eye/face wash heads from contaminants. (Sections 5.1.3, 6.1.3, 7.1.2, 7.1.3)
- Flow Rates: **Eyewash** unit delivers a minimum of .4 GPM (1.5 L/Min) for 15 minutes. (Section 5.1.6) **Eye/face wash** unit delivers a minimum of 3.0 GPM (11 L/Min) for 15 minutes. (Section 6.1.6)
- Use flow meter to check flow rate; use test gauge to test flow pattern. (Sections 5.1.8, 5.3.1, 6.1.7, 6.3, 7.1.2, 7.1.3)
- Environmental conditions often require freeze or scald protection equipment. (Sections 4.5.5, 5.4.5, 6.4.5, 7.1.1, 7.1.2, 7.1.3)

## Top down view

Requires a 16" (406 mm) radius from the center of the drench shower spray pattern to be free of obstructions. (Sections 4.1.4, 7.1.1) **3**

Required to be free of obstructions a minimum of 6" (152 mm) from the outside of the eye or eye/face wash sprayheads. (Sections 5.4.4, 6.4.4, 7.1.2, 7.1.3)

Use a Bradley test gauge (Model 269-1444) to check flow pattern. **4**



15-minute Flush	Tepid Water	Third-Party Certifications	Weekly Activations:	Annual Inspections
Compliant showers release a continuous flow of at least 20 GPM (76 L/Min) of tepid flushing fluid for a period of at least 15 minutes. (Sections 4.1.4, 4.4.1, 4.5.5, 4.5.6, 7.1.1) Compliant eye or eye/face wash fixture releases a continuous flow of flushing fluid for a minimum of 15 minutes. (Sections 5.1.6, 5.4.5, 5.4.6, 6.1.6, 6.4.5, 6.4.6, 7.1.2, 7.1.3)	(lukewarm) 60–100°F (15.6–37.8°C) encourages full 15-minute flush or until medical personnel arrive. (Definitions, Sections 4.5.6, 5.4.6, 6.4.6, Appendix B6)	Manufacturers may have their safety fixtures independently evaluated by a third-party testing organization. Look for certification when selecting a compliant fixture. (Definitions)	Flush lines and test by activating weekly. Inspection tags are often included with fixtures to document testing and to satisfy a safety audit. (Sections 4.6.2, 5.5.2, 6.5.2, 7.5.2)	ANSI recommends a comprehensive annual inspection of the facility to evaluate modified work space, assess new hazards introduced into the area, and to identify fixtures needing replacement or repair. (Section 7.5.5) (Section 4.6.5)



# Combination Drench Showers and Eye and Eye/Face Washes

## Combination Drench Showers and Eyewash Units

### S19314EW

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic showerhead and bowl

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314EW

### S19314PZ

Same features as S19314P except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

### S19314SB

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic showerhead and stainless steel bowl

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314SB

### S19314EWZ

Same features as S19314EW except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

### S19314EWZS

All stainless steel piping

Plastic showerhead and bowl

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



S19314EWZS

### S19314SBZ

Same features as S19314SB except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

### S19314SBZS

All stainless steel piping

Plastic showerhead and stainless steel bowl

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



S19314SBZS

### S19314P

8' (2.4 m) hand-held drench hose for body rinse

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic showerhead and bowl

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314P



## S19314LL

Hand or foot operation for Eyewash

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic showerhead and stainless steel bowl

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



## S19314FZ

Same features as S19314F except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

## S19314FZS

All stainless steel piping

Plastic showerhead with stainless steel shroud and stainless steel bowl

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



## S19314LLZ

Same features as S19314LL except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

## S19314LLZS

Hand or foot operation for Eyewash

All stainless steel piping

Plastic showerhead and stainless steel bowl

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



## S19314UU

Hand or foot operation for Eyewash

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic showerhead with stainless steel shroud and stainless steel bowl

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



## S19314F

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic showerhead with stainless steel shroud and stainless steel bowl

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



## S19314UUZ

Same features as S19314UU except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2



## Combination Drench Showers and Eye and Eye/Face Washes

### S19314UUZS

Hand or foot operation for Eyewash

All stainless steel piping

Plastic showerhead with stainless steel shroud and stainless steel bowl

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



S19314UUZS

### S19314DC

Galvanized steel protected with BradTest corrosion-resistant yellow coating

Plastic showerhead and stainless steel bowl and dust cover

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314DC

### S19314DCZ

Same features as S19314DC except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

## Combination Drench Showers and Eyewash Units with Hinged Dust Covers

### S19314PDC

Galvanized steel protected with BradTest corrosion-resistant yellow coating

Plastic showerhead, bowl and dust cover

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314PDC

### S19314DCZS

All stainless steel piping

Plastic showerhead and stainless steel bowl and dust cover

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



S19314DCZS

### S19314PDCZ

Same features as S19314PDC except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

### S19314PDCZS

All stainless steel piping

Plastic showerhead, bowl and dust cover

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



S19314PDCZS

## Combination Drench Showers and Eye/Face Wash Units

### S19314FW

Dual eye/face wash

Galvanized steel protected with BradTest corrosion-resistant yellow coating

Plastic showerhead and bowl

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314FW



## S19314FWZ

Same features as S19314FW except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

## S19314FWZS

Dual eye/face wash

All stainless steel piping

Plastic showerhead and bowl

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



S19314FWZS

## S19314SBFW

Dual eye/face wash

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic showerhead and stainless steel bowl

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314SBFW

## S19314SBFWZ

Same features as S19314SBFW except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

## S19314SBFWZS

Dual eye/face wash

All stainless steel piping

Plastic showerhead and stainless steel bowl

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



S19314SBFWZS

## S19314AC

Hand or foot operation for eye/face wash

Dual eye/face wash

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic showerhead and stainless steel bowl

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314AC

## S19314ACZ

Same features as S19314AC except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2



Combination Drench Showers and Eye and Eye/Face Washes

<b>S19314ACZS</b>
Hand or foot operation for eye/face wash
Dual eye/face wash
All stainless steel piping
Plastic showerhead and stainless steel bowl
Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)
BSPP thread
Certified to AS4775 and AS4020
Listed by Intertek to EN 15154-1 and 15154-2



S19314ACZS

<b>S19314TTZS</b>
Dual eye/face wash
All stainless steel piping
Plastic showerhead with stainless steel shroud and stainless steel bowl
Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)
BSPP thread
Certified to AS4775 and AS4020
Listed by Intertek to EN 15154-1 and 15154-2



S19314TTZS

<b>S19314TT</b>
Dual eye/face wash
Galvanized steel protected with BradText corrosion-resistant yellow coating
Plastic showerhead with stainless steel shroud and stainless steel bowl
Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)
UL classified to meet ANSI/ISEA Z358.1
Listed by Intertek to EN 15154-1 and 15154-2



S19314TT

Combination Drench Showers and Eye/Face Wash Units

<b>S19314SPR</b>
Hand or foot operation for eye/face wash
Dual eye/face wash
Galvanized steel protected with BradText corrosion-resistant yellow coating
Stainless steel showerhead and bowl
Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)
UL classified to meet ANSI/ISEA Z358.1
Listed by Intertek to EN 15154-1 and 15154-2



S19314SPR

<b>S19314TTZ</b>
Same features as S19314TT except with BSPP thread
Listed by Intertek to EN 15154-1 and 15154-2

<b>S19314SPRZ</b>
Same features as S19314SPR except with BSPP thread
Listed by Intertek to EN 15154-1 and 15154-2



## S19314SPRZS

Hand or foot operation for eye/face wash

Dual eye/face wash

All stainless steel piping

Stainless steel showerhead and bowl

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020



S19314SPRZS

## S19314BFPBZS



Barrier-free design – fully accessible to people with physical disabilities

Dual eye/face wash

All stainless steel piping

Plastic showerhead and bowl

Eyewash exceeds minimum water flow of 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



S19314BFPBZS

## S19314BFPB



Barrier-free design – fully accessible to people with physical disabilities

Dual eye/face wash

Galvanized steel protected with BradText corrosion-resistant yellow coating

Plastic showerhead and bowl

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314BFPB

## S19314BF



Barrier-free design – fully accessible to people with physical disabilities

Dual eye/face wash

Galvanized steel protected with BradText corrosion-resistant yellow coating

Plastic showerhead and stainless steel bowl

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314BF

## S19314BFPBZ



Same features as S19314BFPB except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

## S19314BFZ



Same features as S19314BF except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2



## Combination Drench Showers and Eye and Eye/Face Washes

### S19314BFZS



Barrier-free design – fully accessible to people with physical disabilities

Dual eye/face wash

All stainless steel piping

Plastic showerhead and stainless steel bowl

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



S19314BFZS

### S19314PDCFWZS

Dual eye/face wash

All stainless steel piping

Plastic showerhead, bowl and dust cover

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



S19314PDCFWZS

## Combination Drench Showers and Eye/Face Wash Units with Hinged Dust Covers

### S19314PDCFW

Dual eye/face wash

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic showerhead, bowl and dust cover

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314PDCFW

### S19314DCFW

Dual eye/face wash

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic showerhead and stainless steel bowl and dust cover

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314DCFW

### S19314PDCFWZ

Same features as S19314PDCFW except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

### S19314DCFWZ

Same features as S19314PDCFW except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

### S19314DCFWZS

Dual eye/face wash

All stainless steel piping

Plastic showerhead and stainless steel bowl and dust cover

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



S19314DCFWZS



## S19314DCBF



Barrier-free design – fully accessible to people with physical disabilities

Dual eye/face wash

Galvanized steel protected with BradText corrosion-resistant yellow coating

Plastic showerhead and stainless steel bowl and dust cover

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314DCBF

## Combination Drench Shower and Eye/Face Wash Units without Eyewash Bowl

## S19314GG

Dual eye/face wash

Galvanized steel protected with BradText corrosion-resistant yellow coating

Plastic showerhead and no bowl

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 and 15154-2



S19314GG

## S19314DCBFZ



Same features as S19314DCBF except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

## S19314GGZ

Same features as S19314GG except with BSPP thread

Listed by Intertek to EN 15154-1 and 15154-2

## S19314DCBFZS



Barrier-free design – fully accessible to people with physical disabilities

Dual eye/face wash

All stainless steel piping

Plastic showerhead and stainless steel bowl and dust cover

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



S19314DCBFZS

## S19314GGZS

Dual eye/face wash

All stainless steel piping

Plastic showerhead and no bowl

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

BSPP thread

Certified to AS4775 and AS4020

Listed by Intertek to EN 15154-1 and 15154-2



S19314GGZS



## Frost-Proof, Wall-Mounted Combination Drench Shower and Eyewash

### S19-310TW



Through-wall design

Galvanized steel protected with BradTect corrosion-resistant yellow coating

Plastic showerhead and no bowl

Available in three wall thicknesses:

S19-310TW8 0–8" (0–203 mm)

S19-310TW12 8–12" (203–305 mm) – standard

S19-310TW18 12–18" (305–457 mm)

UL classified to meet ANSI/ISEA Z358.1



S19-310TW

### S19314FSS

All stainless steel fixture

Bradley's stainless steel emergency fixtures are recommended for harsh environments

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 & EN 15154-2



S19314FSS

### S19314FSSZ

Same features as S19314FSS except with BSPP thread

Listed by Intertek to EN 15154-1 & EN 15154-2

Certified to AS4775 and AS4020

## All Stainless Steel Combination Drench Showers and Eyewash or Eye/Face Wash Units

### S19314BFSS



Barrier-free design – fully accessible to people with physical disabilities

All stainless steel fixture

Corrosion-resistant for harsh environments

Bradley's stainless steel emergency fixtures are recommended for harsh environments

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 & EN 15154-2



S19314BFSS

### S19314SC

All stainless steel fixture and dust cover

Bradley's stainless steel emergency fixtures are recommended for harsh environments

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 & EN 15154-2



S19314SC

### S19314BFSSZ



Same features as S19314BFSS except with BSPP thread

Listed by Intertek to EN 15154-1 & EN 15154-2

Certified to AS4775 and AS4020

### S19314SCZ

Same features as S19314SC except with BSPP thread

Listed by Intertek to EN 15154-1 & EN 15154-2

Certified to AS4775 and AS4020



## S19314SS

Hand or foot operation for eye/face wash

All stainless steel fixture

Bradley's stainless steel emergency fixtures are recommended for harsh environments

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 & EN 15154-2



S19314SS

## S19-310PVC

Corrosion-resistant schedule 80PVC

Stainless steel valve fittings

Plastic showerhead and bowl

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1



S19-310PVC

## S19314SSZ

Same features as S19314SS except with BSPP thread

Listed by Intertek to EN 15154-1 & EN 15154-2

Certified to AS4775 and AS4020

## S19314SS16

Fixture is all type 316 corrosion-resistant stainless steel for harsh environments

Bradley's stainless steel emergency fixtures are recommended for harsh environments

Eye/face wash exceeds minimum water flow of 3 GPM (11 L/Min) at 30 psi (207 kPa)

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1 & EN 15154-2



S19314SS16

## S19314SS16Z

Same features as S19314SS16 except with BSPP thread

Listed by Intertek to EN 15154-1 & EN 15154-2

Certified to AS4775 and AS4020





### Drench Showerheads

Bradley's drench showers are available with either a plastic or stainless steel showerhead. The plastic showerheads are high-visibility yellow and made of impact-resistant material. For the most durable showerhead, select stainless steel which stands up to corrosion and aggressive impact.



### Eye and Eye/Face Wash Bowls

Bradley's eye and eye/face wash bowls come in two different materials – plastic and stainless steel. The high-visibility plastic bowls are intended for general use. The impact-resistant plastic will stand up to regular wear and tear. For the most durable bowl, select stainless steel bowls for rugged environments, where impact and corrosion could be a problem.



### Dust Covers

The most effective way to keep the unit clean and functioning properly is to have a dust cover over the eye or eye/face wash. See-through plastic dust covers provide effective dust protection, but also allow for easy inspection. These covers automatically open when the eye or eye/face wash is activated. Dust covers are available as standard equipment on many eye and eye/face washes, or can be ordered as a retrofit kit.



### Foot Treadle

Foot treadles provide hands-free activation for eye and eye/face washes. Foot treadles are available as standard equipment on some eye and eye/face washes, or can be ordered as a retrofit kit.



### Flow Controls

In the interest of water conservation, each shower head features an integral 20 GPM (76 L/Min) flow control. This item must be purchased separately for most competing brands.



**Don't see a model that meets your application?** Use the selections below to build one to suit your needs. Select one option from each category. Fill in the squares below with the corresponding option letter or number. Use the resulting alphanumeric number to specify the model and configuration for your desired product.

- [illegible]

- 

- 

- 

- 

- 

- 

- 
- The sequence shows the following steps: 1. A bolt is being inserted into a hole in a metal bracket. 2. A nut is being threaded onto the bolt. 3. The nut is being tightened against the bracket. 4. The final assembly is shown with the nut fully tightened.

- [illegible]



**NEW!**

# S19-304 Series

## Overview

Bradley Heat Trace Showers are engineered to ensure water doesn't freeze in the fixture, down to -50°F (-46°C). These durable freeze protected showers help keep employees safe in extreme, frigid environments. The high-visibility fixture is insulated and covered by a yellow plastic shell, it features an integral freeze protection bleed valve, and is electrically rated for use in General Area, Class I Division 2, Class I Division 1, and Class II Division 1 and 2 locations.

Heat trace fixtures are available with an optional signaling system, indicator light, extension cable, drench hose, stainless steel material, and anti-scald valve.

## Key Features

- General area and hazardous location models
- Freeze protection valve ensures continual flow of water should power fail
- SpinTec showerhead improves water distribution
- Halo Eyewash technology delivers the most effective washdown coverage
- Bowl and dust cover always included
- Classified by Underwriters Laboratories Inc to ANSI Z358.1

## Emergency Fixture Facts

In geographic areas where an emergency fixture may freeze, safety personnel should consider purchasing a freeze-protected fixture or additional accessories to prevent the pipes from freezing. ANSI/ISEA Z358.1 Section 6.4.5



Model S19-304GATL  
General Area with  
Indicator Lights

## Recommended Emergency TMV

### Navigator EFX 25 (S19-2100)

The current ANSI standard calls for emergency Eyewashes and drench showers to deliver tepid water (60–100°F/ 15.5–37.7°C) for 15 minutes. A thermostatic mixing valve is needed to mix the hot and cold water supply. Bradley's Navigator TMVs are the most reliable emergency TMVs on the market. One valve is required per plumbed unit.





## S19-304GAT

For use in general areas where temperatures fall below freezing

120 VAC protects until from freezing down to -50° F (-46°C)

1 1/4" NPT (top supply)

1 1/4" galvanized steel pipe

3.1" (78.7mm) diameter, impact-resistant plastic SpinTec Showerhead

Halo Eye/Face Wash

ABS Plastic Halo Eye/Face Wash

Ergonomic hand activation Eyewash paddle



S19-304GAT

## S19-304D2T

For use in Class I Division 2 areas where temperatures fall below freezing

120 VAC protects until from freezing down to -50° F (-46°C)

1 1/4" NPT (top supply)

1 1/4" galvanized steel pipe

3.1" (78.7mm) diameter, impact-resistant plastic SpinTec Showerhead

Halo Eye/Face Wash

ABS Plastic Halo Eye/Face Wash

Ergonomic hand activation Eyewash paddle



S19-304D2T

## S19-304GAB

Same features as S19-304GAT except with bottom water supply

## S19-304GATL

For use in general areas where temperatures fall below freezing

120 VAC protects until from freezing down to -50° F (-46°C)

1 1/4" NPT (top supply)

1 1/4" galvanized steel pipe

3.1" (78.7mm) diameter, impact-resistant plastic SpinTec Showerhead

Halo Eye/Face Wash

ABS Bowl and dust cover (transparent cover)

Ergonomic hand activation Eyewash paddle

General Area Indicator Lights



S19-304GATL

## S19-304D2B

Same features as S19-304GAT except with bottom water supply

## S19-304D2TL

For use in Class I Division 2 areas where temperatures fall below freezing

120 VAC protects until from freezing down to -50° F (-46°C)

1 1/4" NPT (top supply)

1 1/4" galvanized steel pipe

3.1" (78.7mm) diameter, impact-resistant plastic SpinTec Showerhead

Halo Eye/Face Wash

ABS Plastic Halo Eye/Face Wash

Ergonomic hand activation Eyewash paddle

Class I Division 2 Indicator Lights



S19-304D2TL

## S19-304GABL

Same features as S19-304GATL except with bottom water supply

## S19-304D2BL

Same features as S19-304D2TL except with bottom water supply



## Heat Trace Combination Drench Shower and Eye/Eye-Face Wash

### S19-304 Series Features

- **Electric heat trace cable:**
  - Thermal rating 5 watts/foot
  - Self regulated to -50°F (-45.5°C)
  - Protects against overheating and cold spots
  - ¾" (19 mm) polyethylene pipe insulation
- **Insulated and covered by high-visibility yellow ABS plastic shell**
  - Easy to maintain
  - Six easy-to-remove sections
- NEMA 4X rated electrical enclosure
- Signaling Systems can be easily added to all units
- Thermostat opens at 64°F (18°C) and closes at 54°F (12°C)
- Four-hub, aluminum junction box accepts ¾" (19 mm) conduit for hazardous locations
- Plastic junction box with one extra ¾" conduit hole for General Area locations
- Freeze valve opens at 35°F (2°C) internal water temperature to prevent freezing
- Stainless steel pull rod with triangular handle
- Chrome-plated brass, stay-open ball valve
- ½" (13 mm) Eyewash valve
- 1" (25 mm) shower valve
- UL Plumbing listed to meet ANSI/ISEA Z358.1
- CSA electrical certification for use in United States and Canada (cCSAus)

**Additional product information, including Technical Data and Installation Instructions, is available online at [bradleycorp.com](http://bradleycorp.com).**

Standard selections are in bold.

Selection should be made in each category.  
Incoming supply (top or bottom) must be indicated.

#### Electrical Class

- ☐ **GA General Area**
- ☐ **D2 Class I Div 2 – Groups B, C, D**
- ☐ D1 Class I Div 1 – Groups C, D
- ☐ C2 Class II Div 1 and 2– Groups E, F & G

#### Voltage

- ☐ **V1 120V**
- ☐ V4 240V

#### Water Supply

- ☐ T Top Supply
- ☐ B Bottom Supply

#### Pipe and Ball Valve Material

- ☐ **GLV Galvanized Pipe and Chrome-Plated Brass Ball Valve**
- ☐ 304 304SS Pipe, 316 SS Ball Valve
- ☐ 316 316SS Pipe, 316 SS Ball Valve

#### Showerhead

- ☐ **SH ABS Plastic Showerhead**
- ☐ SHP ABS Plastic Showerhead with Plastic Shroud
- ☐ SHS ABS Plastic Showerhead with SS Shroud
- ☐ S04 304 SS Showerhead
- ☐ S16 316 SS Showerhead

#### Eyewash

- ☐ EW ABS Plastic Eyewash Only Aluminum Yoke
- ☐ **FW ABS Plastic Eye/Face Wash, Aluminum Yoke**
- ☐ F04 304 SS Eye/Face Wash, 304 SS Yoke\*
- ☐ F16 316 SS Eye/Face Wash, 316 SS Yoke\*

#### Bowl and Cover

- ☐ **PP Plastic Bowl and Cover**
- ☐ B04 304 SS Bowl and Cover
- ☐ P04 304 SS Bowl and Plastic Cover
- ☐ B16 316 SS Bowl and Cover
- ☐ P06 16 SS Bowl and Plastic Cover

#### Activation

- ☐ **HA 300 Series Handle Activation**
- ☐ H16 316 SS Handle Activation
- ☐ HF 300 Series Handle & Foot Activation
- ☐ HF16 316SS Handle and Foot Activation

#### Indicator Light

- ☐ **O No Light**
- ☐ L General Area Light
- ☐ D2L Class I, Division 2 Light
- ☐ D1L Class I, Division 1 Light
- ☐ C2L Class II Light

#### Drench Hose

- ☐ **O No Drench Hose**
- ☐ H Drench Hose

#### Anti-Scald Valve

- ☐ **O No Anti-Scald Valve**
- ☐ S Anti-Scald Valve

#### Extension Cable

- ☐ **O No Extension Cable**
- ☐ E Extension Cable

*\*Must select stainless steel yoke if ordering 304 or 316 stainless steel pipe.*

### Recommended Option:

#### S19-324 Series Signaling Systems (pg 56)

According to ANSI guidelines, audible signaling systems may be a desirable accessory to audibly or electronically alert safety personnel that an emergency occurred. (ANSI/ISEA Z358.1)







## INDOOR & OUTDOOR MODELS

### Overview

Protect your people from extreme environments with a customized safety solution. Turnkey shower, Eyewash and drench hose systems offer an injured party a humane triage experience. Enclosed safety systems address the physical and psychological needs of the injured party by providing privacy, delivering warm water, warm ambient temperature and a shelter from the elements. Armed with a fire-rated insulated fiberglass structure, tepid water delivery capabilities, and reliable chemical and corrosion resistance, Bradley's enclosed safety shower provides superior washdown capability in emergency situations, while withstanding harsh chemicals.

### Key Features

- Innovative drenching technology featuring:  
SpinTec showerhead for improved water distribution  
Halo rinsing platform
- **Superior design standards:**  
Fiberglass-Reinforced Plastic  
R-8 insulation rating  
Indoor and Outdoor models
- **Premium features come standard:**  
Integral drain  
Portable  
Drench hose
- Flame-retardant resin with a Class 1 Flame Spread Index per ASTM E-84
- 100% fiberglass surround construction highly resistant to chemicals and corrosion
- Ideal for both indoor and outdoor applications
- Custom engineered systems available

### Emergency Fixture Facts

Safety systems with multiple drenching platforms, (shower, Eyewash and drench hose) must be capable of simultaneous activation while delivering tepid water for a duration of 15 minutes. ANSI/ISEA Z358.1 Section 7.4.4

An enclosure is recommended to protect against cold ambient temperatures. ANSI/ISEA Z358.1 Appendix B6





S19372

Indoor Enclosed Safety Showers

**S19372 SERIES**

Tepid water inlet

**S19374 SERIES**

Hot water tank

**S19378 SERIES**

Tankless hot water heater



S19388

Outdoor Enclosed Safety Showers

**S19382 SERIES**

Tepid water inlet

**S19384 SERIES**

Hot water tank

**S19387 SERIES**

Self-contained

**S19388 SERIES**

Tankless hot water heater






# Quick Compliance Guide

This guide serves as a supplement to the ANSI/ISEA Z358.1-2014 standard.

## Enclosed Safety Showers

- Colder ambient temperature may require an enclosure for added protection. (Section B6)
- Valve mechanism opens in one second or less; it stays open until manually closed. (Sections 4.2, 5.2, 6.2, 7.1.1, 7.1.2, 7.1.3)
- Drench shower and eye or eye/face wash must operate simultaneously. (Section 7.4.4)
- Supply with flushing fluid ("potable water, preserved water, preserved buffered saline solution or other medically acceptable solution..."). (Definitions, Sections 4.1.1, 4.4.1, 5.1.1, 6.1.1, 7.1.2, 7.1.3)
- Locate 10 seconds or 55' (16.8 m) from contaminants or hazardous materials. Locate on same plane as the hazard, free of obstructions. (Sections 4.5.2, 5.4.2, 6.4.2, 7.1.1, 7.1.2, 7.1.3, 7.4.2, Appendix B5)
- Must resist corrosion in the presence of flushing fluid (Sections 4.1.5, 5.1.5, 6.1.5, 7.1.1, 7.1.2, 7.1.3)
- Protect eye and eye/face wash heads from contaminants. (Sections 5.1.3, 6.1.3, 7.1.2, 7.1.3)
- Requires a 16" (406 mm) radius from the center of the drench shower spray pattern to be free of obstructions. (Sections 4.1.4, 7.1.1)
- Required to be free of obstructions a minimum of 6" (152 mm) from the outside of the eye or eye/face wash sprayheads. (Sections 5.4.4, 6.4.4, 7.1.2, 7.1.3)
- Eye/face wash nozzle height 33–45" (83.8–114.3 cm) from standing surface. (Sections 5.4.4, 6.4.4, 7)
- Flow Rates:  
An Eyewash delivers a minimum of .4 GPM for 15 minutes. (Sections 5.1.6, 7.1.2)  
An eye/face wash delivers a minimum of 3.0 GPM (11 L/Min) for 15 minutes. (Sections 6.1.6, 7.1.3)
- Use flow meter to check flow rate; use test gauge to test flow pattern. (Sections 5.1.8, 5.3.1, 6.1.7, 6.3, 7.1.2, 7.1.3)
- Use a Bradley test gauge (Model 269-1444) to check flow pattern. **1**
- Environmental conditions often require freeze or scald protection equipment. (Sections 4.5.5, 5.4.5, 6.4.5, 7.1.1, 7.1.2, 7.1.3)



15-minute Flush	Tepid Water	Third-Party Certifications	Weekly Activations:	Annual Inspections
Compliant showers release a continuous flow of at least 20 GPM (76 L/Min) of tepid flushing fluid for a period of at least 15 minutes. (Sections 4.1.4, 4.4.1, 4.5.5, 4.5.6, 7.1.1) Compliant eye or eye/face wash fixture releases a continuous flow of flushing fluid for a minimum of 15 minutes. (Sections 5.1.6, 5.4.5, 5.4.6, 6.1.6, 6.4.5, 6.4.6, 7.1.2, 7.1.3)	(Lukewarm) 60–100°F (15.6–37.8°C) encourages full 15-minute flush or until medical personnel arrive. (Definitions, Sections 4.5.6, 5.4.6, 6.4.6, Appendix B6)	Manufacturers may have their safety fixtures independently evaluated by a third-party testing organization. Look for certification when selecting a compliant fixture. (Definitions)	Flush lines and test by activating weekly. Inspection tags are often included with fixtures to document testing and to satisfy a safety audit. (Sections 4.6.2, 5.5.2, 6.5.2, 7.5.2)	ANSI recommends a comprehensive annual inspection of the facility to evaluate modified work space, assess new hazards introduced into the area, and to identify fixtures needing replacement or repair. (Section 7.5.5) (Section 4.6.5)





# Eye/Face Wash and Shower Models

## Overview

The safety of your employees is paramount. Keltech electric tankless emergency water heaters control systems are engineered to ensure that water temperature is just right – not too hot, not too cold. Under constant flow and pressure, temperatures stay within  $\pm 1^{\circ}\text{F}$  of set point. If the flow rate changes drastically, there is no need to worry about being scalded. These units sense the transition and purge latent heat, keeping the output temperature below  $90^{\circ}\text{F}$  ( $32^{\circ}\text{C}$ ). A separate set of circuits monitors for "over temperature" conditions. Large internal passageways minimize pressure drop.

These units perform on demand for efficient energy usage. Unlike boilers, tankless water heaters only draw energy when needed. Utility costs are minimized because there is no need to keep a 300 gal (1136 L) tank heated 24/7/365. Easy to install – just add water and power. All you need is one electrical connection and a cold water line. All models are precision-engineered with materials, such as copper tubing and robust brass castings, that exceed the standards of any application – anywhere in the world.

## Key Features

- No need to keep a 300 gal (1136 L) tank heated 24/7/365
- Easy to install – just add water and power. All you need is one electrical connection and a cold water line
- Under constant flow and pressure, temperatures stay within  $\pm 1^{\circ}\text{F}$  of set point
- Precision systems custom engineered to fit your application
- Meets ANSI/ISEA Z358.1 standards and third-party verified to UL/CSA standards
- Only electric tankless tempering systems that can be ASME and NB certified
- Optional features include NEMA 4X stainless steel enclosures, explosion proof purge system, and freeze protection to  $-20^{\circ}\text{F}$  ( $-28^{\circ}\text{C}$ )

## Emergency Fixture Facts

ANSI requires that an emergency fixture be supplied with tepid flushing fluid between  $60\text{--}100^{\circ}\text{F}$  ( $15.5\text{--}37.7^{\circ}\text{C}$ ) to avoid premature cessation of the recommended 15 minute flush. ANSI/ISEA Z358.1 Section 7.4.5, Appendix B6

**Brass/Copper heat exchangers meet NSF/ANSI 372**

**ASME Certification: Keltech units 63 kW and higher are the only electric tankless water heaters registered with the National Board and certified with the HLW stamp**

**For information contact your Bradley Representative or visit [bradleycorp.com](http://bradleycorp.com)**



## For Safety Eye/Face Wash Applications

### CLE SERIES

kW Range 18 – 25 kW

Flow Range 0.75 – 10 GPM (3 – 37.8 L/Min)

Standard Voltages 480V, 600V 3-Phase Delta

Temperature output fixed at 80°F (27°C)

Meets the ANSI/ISEA Z358.1 standards

Provide continuous tepid water for multiple incidents with zero recovery time and custom-tuned for minimal overshoot

85,000 - 170,000 BTUs

Manual reset cutoff

Auto reset high limit switch

Liquid-cooled solid state relays

NEMA 4 enclosure

Wall- or floor-mounted

¾" (19 mm) connections

ETL and cETL certified to UL and CSA Standards

Temperature safety values:  
Controller alarm 90°F (32°C)  
Auto reset high limit switch 95°F (35°C)  
Manual reset cutoff 100°F (38°C)



### SNA SERIES

kW Range 36 – 144 kW

Flow Range 1.5 – 50 GPM (5.7 – 189.2 L/Min)

Standard Voltages 480V, 600V 3-Phase Delta

Temperature output fixed at 80°F (27°C)

Meets the ANSI/ISEA Z358.1 standards

Provide continuous tepid water for multiple incidents with zero recovery time and custom-tuned for minimal overshoot

Dual flow activation for reduced overshoot and energy savings

122,800 – 491,300 BTUs

Manual reset cutoff

Auto reset high limit switch

Door cutoff switch

Emergency stop button

Liquid-cooled solid state relays

NEMA 4 enclosure

Floor-mounted

1¼" (32 mm) connections

ETL and cETL certified to UL and CSA Standards

Temperature safety values:  
Controller alarm 90°F (32°C)  
Auto reset high limit switch 95°F (35°C)  
Overshoot purge 95°F (35°C)  
Manual reset cutoff 100°F (38°C)



## For Safety Shower Applications

### S19361

Pre-assembled safety fixture and SNA heater skid system

Halo™ Eye/Face Wash and SpinTec™ Drench Shower

54 – 144 kW (491,300 BTUs)

Molded Duragrate® and integrated shower pan

Temperature overshoot purge system

NEMA 4 enclosure standard

AL3 building communication alarm included

Dual Flow Heater Activation  
(Eye/Face Wash and/or Shower)

Internal fusing (included) adds safety and permits single power connection

Controller-locked temperature setting, output fixed at 80°F (27°C)

Meets ANSI/ISEA Z358.1 standards

ETL and cETL certified to UL and CSA Standards

Emergency stop button and door cutoff switch



### S19361HF NEW!

Pre-assembled, freeze-protected safety fixture and SNA heater skid system

Bradley Halo Heat Trace S19-304 with SpinTec™

54 – 144 kW (491,300 BTUs)

Molded Duragrate® and integrated shower pan

Temperature overshoot purge system

NEMA 4 heat enclosure standard

AL3 building communication alarm option included

Dual Flow Heater Activation  
(Eye/Face Wash and/or Shower)


Internal fusing (included) adds safety and permits single power connection

Controller-locked temperature setting, output fixed at 80°F (27°C)

Meets ANSI/ISEA Z358.1 standards

ETL and cETL certified to UL and CSA Standards

Emergency stop button and door cutoff switch







## Emergency Thermostatic Mixing Valves

### Overview

Bradley's Navigator® emergency thermostatic mixing valves provide tepid water (60–100°F/15.5°–37.7°C) by mixing cold and hot water to a predetermined temperature. Tepid water encourages injured workers to remain beneath the deluge of water released from the emergency fixture, for the entire ANSI required 15-minute flush. ANSI/ISEA Z358.1-1998 first required tepid water and the 2004 standard outlined that definition of the temperature range in its appendix. Each Navigator Emergency TMV features a fixed cold-water bypass that will allow cold water to flow should the hot water exceed the predetermined temperature reflecting Bradley's commitment to customers, quality and its dedication to manufacturing quality products that protect your employees.

### Key Features

- Reliable, liquid-filled thermostat
- Accurate temperature control to within  $\pm 3^\circ$
- Dial thermometer
- Checkstops on inlets
- Built-in cold water bypass
- Positive shut-off of hot supply when cold supply is lost
- Dirt and lime resistant
- Factory assembled and tested
- Universal mounting capability
- Valves are preset at 85°F (29°C) and are adjustable from 65°F (18°C) to 95°F (35°C)
- All items comply with ANSI/ISEA Z358.1



S19-2000 EFX8



S19-2100 EFX25



S19-2300 EFX125

### Emergency Fixture Facts

ANSI requires that an emergency fixture be supplied with tepid flushing fluid between 60–100°F (15.5°–37.7°C). ANSI/ISEA Z358.1 Section 7.4.5, Appendix B6



## Thermostatic Mixing Valves

S19-2000 *	7 GPM (26 L/Min) @ 30 psi (207 kPa)	Accommodates one Eyewash or eye/ face wash
S19-2100	26 GPM (98 L/Min) @ 30 psi (207 kPa)	Accommodates one combination shower, one drench shower or multiple Eyewashes
S19-2150 *	19.5 GPM (74 L/Min) @ 30 psi (207 kPa)	Accommodates one drench shower or multiple Eyewashes
S19-2200	53.5 GPM (203 L/Min) @ 30 psi (207 kPa)	Accommodates up to two combination showers, two drench showers or multiple Eyewashes
S19-2250 *	48 GPM (182 L/Min) @ 30 psi (207 kPa)	Accommodates one combination shower, up to two drench showers or multiple Eyewashes
S19-2300	82 GPM (310 L/Min) @ 30 psi (207 kPa)	Accommodates up to three combination showers, three drench showers or multiple Eyewashes
S19-2350 *	72.5 GPM (274 L/Min) @ 30 psi (207 kPa)	Accommodates up to two combination showers, three drench showers, or multiple Eyewashes

ANSI Standard Z358.1 requires tempered water supply. Ratings provided at 30 psi (207 kPa), the minimum pressure required by ANSI/ISEA Z358.1 to be supplied to Eyewash, eye/face wash and combination units. Reference Bradley's Technical Data Sheets for a full listing of flow capacities.

\* ASSE 1071 and cUPC certified

## Additional Product Options

Finish	
R	Rough Brass (Standard)
C	Chrome-plated
Piped Assembly	
P*	Piped assembly with inlet and outlet shutoff
N*	Piped assembly only
Cabinets	
SS	Surface-mounted stainless steel
RS	Recessed stainless steel
SE	Surface-mounted white enamel
RE	Recessed white enamel
W	Plexiglas® window in door

\* Option not available with S19-2000.  
Standard with cabinet-mounted valves.

## Navigator Skid Systems

The Bradley Navigator Skid is engineered for industrial applications that need a skid-mounted, TMV based tepid water system. The flexible design allows for recirculation system, booster pump, and larger storage tank options. One supply inlet and one power supply connection provide a tepid water system for one or more emergency Eyewash or drench showers.

### MODEL: NTS1

General Area or Class I Division 2 Electrical Class

208V, 240, or 480V Supply Voltage

**119-gallon standard or ASME Hot Water Tank**

**Optional Pressure Booster Pump, Recirculation Pump, Return Line, and Aquastat**

### MODEL: NTS2

General Area or Class I Division 2 Electrical Class

208V, 240, or 480V Supply Voltage

**318-gallon ASME Hot Water Tank**

**Optional Pressure Booster Pump, Recirculation Pump, Return Line, and Aquastat**







# Emergency Signaling Systems

## Overview

Whether your intent is to prevent vandalism caused by false activations, or to be sure your safety team and medical personnel are notified during an emergency, signaling systems may be the solution. Each Bradley signaling system is equipped with a double pole, double throw flow switch. To complement the audible and visual indicator, each flow switch and central control board provides extra sets of contacts necessary to connect the fixture to a central control system that monitors the fixture. Signaling systems provide peace of mind, they discourage vandals, yet notify safety personnel when and where an emergency occurs.

## Key Features

- Automatic, audible and visual system
- Signal light and horn activate when shower or Eyewash is activated; pre-assembled
- Optional beacon or area lights
- Optional silence switch with auto reset
- Universal AC Input: 90-264 AC, 50-60 Hz
- Requires a minimum of 2.4 GPM (9 L/Min) water flow to activate
- ½" (13 mm) or 1¼" (32mm) NPT inlet piping
- Double pole, double throw flow switch

## Emergency Fixture Facts

According to ANSI guidelines, audible signaling systems may be a desirable accessory to audibly or electronically alert safety personnel that an emergency occurred. ANSI/ISEA Z358.1, Appendix B4

Don't see the product you are looking for? Go to pages 60–62 to use the S19-324 Configurators



## S19-322 Series

- Recessed signaling system
- Automatic, audible and visual signal system
- Signal light and horn activate when shower or eye wash is activated; preassembled
- ½" (13mm) or 1¼" (32mm) NPT inlet piping
- Double pole, double throw flow switch
- For indoor applications
- Universal AC Input: 90-264 AC, 50-60 Hz
- NEMA 1 signaling system

### S19-322E

- UL listed ½" (32mm) flow switch
- Flashing amber LED signal light
- For eye or eye/face washes



### S19-322D

- UL listed 1¼" (32mm) flow switch
- Flashing amber LED signal light
- For drench showers or combination units



## S19-323 Series

- Automatic, audible and visual signaling system
- Signal light and horn activate when Eyewash or shower is activated; preassembled
- Requires a minimum of 2.4 GPM (9 L/Min) water flow to activate
- ½" (13 mm) or 1¼" (32mm) NPT inlet piping
- Double pole, double throw flow switch
- For indoor and outdoor applications
- Extra set of contacts on central control board
- 6' (1.8 m) cable
- Universal AC Input: 90-264 AC, 50-60 Hz
- NEMA 3R signaling system

### S19-323E

- UL listed ½" (13 mm) brass flow switch
- For eye or eye/face wash
- Amber signal light



### S19-323D

- UL listed 1¼" (32mm) brass flow switch
- For drench shower or combination units
- Amber signal light





## S19-324 Series

- Automatic, audible and visual signaling system
- Signal light and horn activate when eye wash or shower is activated; pre-assembled
- Requires a minimum of 2.4 GPM (9 L/Min) water flow to activate
- ½" (13 mm) or 1¼" (32mm) NPT inlet piping
- Double pole, double throw flow switch
- For indoor and outdoor applications
- Extra set of contacts on central control board
- Universal AC Input: 90-264 AC, 50-60 Hz

### S19-324E

Brass UL listed ½" (13mm) flow switch  
NEMA 4X signaling system  
6' (1.8 m) Cable  
For eye or eye/face wash  
Silence switch with auto reset  
Amber signal light



S19-324E

### S19-324D

Brass, UL listed 1¼" (32 mm) flow switch  
NEMA 4X signaling system  
6' (1.8 m) Cable  
For drench showers or combination units  
Silence switch with auto reset  
Amber signal light



S19-324D

### S19-324DG, S19-324DGW

Brass UL listed 1¼" (32 mm) flow switch  
NEMA 4X signaling system  
6' (1.8 m) Cable  
Silence switch with auto reset  
Green beacon light  
White area light (S19-324DGW only)  
For drench showers or combination units  
Amber signal light



S19-324DGW

### S19-324EG, S19-324EGW

UL listed ½" (13mm) brass flow switch  
NEMA 4X signaling system  
6' (1.8 m) Cable  
Silence switch with auto reset  
Green beacon light  
White area light (S19-324EGW only)  
For eye wash or eye/face washes  
Amber signal light



S19-324EGW

## Explosion-Proof Emergency Signaling System (Class 1 Division 2, Groups B, C & D)

### S19-324D2D

NEMA 4X  
Brass UL listed 1¼" (32 mm) flow switch  
For drench shower or combination units  
Amber signal light  
S19-324D2DHT for S19-304  
heat trace combination units



S19-324D2D

## Explosion-Proof Emergency Signaling System (Class 1 Division 1, Groups C & D)

### S19-324D1D

NEMA 4X  
Brass UL listed 1¼" (32 mm) flow switch  
For drench shower or combination units  
Amber signal light  
S19-324D1DHT for S19-304  
heat trace combination units



S19-324D1D



## Flow Switches

**S19-319B2**

Brass

1/2" (13 mm) NPT

Activates Eyewash and eye/face wash units



S19-319B2

**S19-319S2**

Stainless steel

1/2" (13 mm) NPT

Activates Eyewash and eye/face wash units



S19-319S2

**S19-319B4**

Brass

1 1/4 NPT

Activates combination units



S19-319B4

**S19-319S4**

Stainless steel

1 1/4 NPT

Activates combination units



S19-319S4

For availability on a brass or stainless steel flow switch only,  
contact Bradley Customer Service at 800-BRADLEY (800.272.3539)















# S19-324 Series Configurator

**Don't see a model that meets your application?** Use the selections below to build one to suit your needs. Select one option from each category. Fill in the squares below with the corresponding option letter or number. Use the resulting alphanumeric number to specify the model and configuration for your desired product.

## Model S19-324

General Area, NEMA4X, Signal System

<div>   </div>		<b>1</b> Fixture Configuration	<div>   </div>		<b>5</b> Signal Light
EF	Eye or Eye/Face Wash		SA	Amber (Flashing)	
DC	Drench or Combination		SR	Red (Flashing)	
HT	Halo Heat Trace Combination Unit*		<b>6</b> Beacon Light		
<div>   </div>		<b>2</b> Activation	<div>   </div>		<b>0</b> None
BS	Brass Flow Switch		BG	Green (Steady)	
SS	Stainless Steel Flow Switch		BB	Blue (Steady)	
<div>  </div>		<b>3</b> Horn Sound	<b>7</b> Area Light (Steady)		
TN1	Tone 1		O	None	
TN2	Tone 2		<div>   </div>		
TN3	Tone 3		AW	White (Steady)	
<div>  </div>		<b>4</b> Silence Switch	AR	Red (Steady)	
O	None		<b>8</b> Cable Length (Flow Switch to Signaling System)		
PM	Panel Mount		C6	6' Cable	
FM	Flex Mount with 15' Cable		C12	12' Cable	
			C50	50' Cable	

\* Signaling system can only be mounted to new style S19-304 Halo Heat Trace Combination Unit

Fill in 1 through 8 to specify the model and configuration for your desired project:

						<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>
S	1	9	3	2	4								















## S19-324D1 Series Configurator

**Don't see a model that meets your application?** Use the selections below to build one to suit your needs. Select one option from each category. Fill in the squares below with the corresponding option letter or number. Use the resulting alphanumeric number to specify the model and configuration for your desired product.

## Model S19-324D1

## Class I, Division 1, Groups C, and D Signal System

	<b>1</b> Fixture Configuration		<b>5</b> Silence Switch		<b>9</b> Cable Length
	<b>EF</b> Eye or Eye/Face Wash		<b>0</b> None		
	<b>DC</b> Drench or Combination		<b>RS</b> Reset Switch		<b>C6</b> 6' Cable
	<b>HT</b> Halo Heat Trace Combination Unit*				<b>C12</b> 12' Cable
	<b>2</b> Mounting		<b>6</b> Signal Light		<b>C50</b> 50' Cable
	<b>PT</b> Pipe Mount		<b>SA</b> Amber (Flashing)		
	<b>WM</b> Wall Mount		<b>SR</b> Red (Flashing)		
	<b>3</b> Activation		<b>7</b> Beacon Light		
	<b>BS</b> Brass Flow Switch		<b>0</b> None		
	<b>SS</b> Stainless Steel Flow Switch		<b>BG</b> Green (Steady)		
			<b>BB</b> Blue (Steady)		
	<b>4</b> Horn Sound		<b>8</b> Area Light		
	<b>TS</b> Standard Single Tone		<b>0</b> None		
	<b>TM</b> Multi-Tone (Installer Mounted)		<b>AW</b> White (Steady)		
			<b>AR</b> Red (Steady)		

\* Signaling system can only be mounted to new style S19-304 Halo Heat Trace Combination Unit

Fill in 1 through 10 to specify the model and configuration for your desired project:

[illegible]











## S19-324D2 Series Configurator

**Don't see a model that meets your application?** Use the selections below to build one to suit your needs. Select one option from each category. Fill in the squares below with the corresponding option letter or number. Use the resulting alphanumeric number to specify the model and configuration for your desired product.

## Model S19-324D2

## Class I, Division 2, Groups B, C, and D Signal System

	<b>1</b> Fixture Configuration		<b>6</b> Signal Light		<b>9</b> Cable Length	
EF	Eye or Eye/Face Wash		SA	Amber (Flashing)	C6	6' Cable
DC	Drench or Combination		SR	Red (Flashing)	C12	12' Cable
HT	Halo Heat Trace Combination Unit*		<b>7</b> Beacon Light	C50	50' Cable	
<b>2</b> Activation			<b>0</b> None			
BS	Brass Flow Switch		BG	Green (Steady)		
SS	Stainless Steel Flow Switch		BB	Blue (Steady)		
	<b>3</b> Horn Sound		<b>8</b> Area Light			
TS	Standard Single Tone		<b>0</b> None			
TM	Multi-Tone (Installer Mounted)		AW	White (Steady)		
	<b>4</b> Silence Switch		AR	Red (Steady)		
	* For use in gas groups C, D only					
<b>0</b> None						
RS	Reset Switch					

\* Signaling system can only be mounted to new style S19-304 Halo Heat Trace Combination Unit

Fill in 1 through 9 to specify the model and configuration for your desired project:

S	1	9	3	2	4	D	2	1	2	3	4	5	6	7	8	9
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---





## S19-460, S19-430 and S19-440 Series

### Overview

Bradley deck-mounted or wall-mounted, dual head drench hoses qualify as an Eyewash when installed according to the ANSI/ISEA Z358.1 guidelines for Eyewashes. A dual head drench hose may be used to flush the eyes or body. In contrast, several single head drench hose models exist exclusively for the purpose of serving as auxiliary safety equipment during an emergency. Single head drench hoses may be deck-mounted, wall-mounted or installed as a retrofit in line with an already existing Eyewash or drench shower in particularly hazardous locations.

### Key Features

- Plastic eye/face wash sprayheads
- 8' (2.4 m) drench hose standard (except where noted)
- Squeeze-activated handle (except where noted)
- Locking clip – continuous water flow once activated
- Deck-mounted models include deck mounting hardware
- Wall-mounted models include wall mounting hardware (except where noted)
- All items comply with ANSI/ISEA Z358.1

### Emergency Fixture Facts

Dual head drench hoses may take the place of a traditional Eyewash if it complies with all Eyewash performance requirements in Section 5 and/or Section 6 of the standard such as being mounted 6" (152 mm) from any obstruction and 33–53" (838–1346 mm) from the top of the spray pattern to the floor.

ANSI/ISEA Z358.1 Section 8.2.1

### Back-flow Preventers

To select the appropriate back-flow preventer, check with local governing authorities on local codes and ordinances.

### Recommended Emergency TMV

#### Navigator EFX 8 (S19-2000)

The current ANSI standard calls for emergency Eyewashes and drench showers to deliver tepid water (60–100°F/15.5–37.7°C) for 15 minutes. A thermostatic mixing valve is needed to mix the hot and cold water supply. Bradley's Navigator TMVs are the most reliable emergency TMVs on the market. One valve is required per plumbed unit.





# Quick Compliance Guide

This guide serves as a supplement to the ANSI/ISEA Z358.1-2014 standard.





## Dual Head Eye/Face Wash & Drench Hose

- Considered an eye/face wash if it complies with the installation and performance requirements of the eye/face wash standard. (Sections 6, 8.2.1)
- Single-head drench hoses complement the 15-minute flush provided by a primary ANSI/ISEA Z358.1 compliant Eyewash fixture. (Section 8)
- Valve mechanism opens in one second or less; it stays open until manually closed. (Sections 6.2, 8.2.1)
- Fixtures compliant as an eye/face wash must remain "on" once activated (Sections 6.2, 8.2.1) ①
- Supply with flushing fluid ("potable water, preserved water, preserved buffered saline solution or other medically acceptable solution...") (Definitions, Sections 6.1.1, 8.2.1) ②
- Locate 10 seconds or 55' (16.8 m) from contaminants or hazardous materials. Locate on same plane as the hazard, free of obstructions. (Section 6.4.2, Appendix B5)
- Protect unit heads from contaminants. (Sections 6.1.3, 8.2.1)
- Flow Rates: Eye/face wash unit delivers a minimum of 3.0 GPM (11 L/Min) for 15 minutes. (Section 6.1.6, 8.2.1)
- Use a flow meter to test flow rate; use a test gauge to test flow pattern. (Sections 6.1.7, 6.3, 8.2.1)

## Top down view

Required to be free of obstructions a minimum of 6" (152 mm) from the outside of the eye or eye/face wash sprayheads. (Sections 6.4.4, 8.2.1) ③

Use a Bradley test gauge (Model 269-1444) to check flow pattern. ④



15-minute Flush	Tepid Water	Third-Party Certifications	Weekly Activations:	Annual Inspections
Compliant fixtures release a continuous flow of tepid flushing fluid for a minimum of 15 minutes. (Sections 6.1.6, 6.4.5, 6.4.6, 8.2.1)	(lukewarm) 60–100°F (15.6–37.8°C) encourages full 15 minute flush or until medical personnel arrive. (Definitions, Sections 6.4.6, 8.2.1, Appendix B6)	Manufacturers may have their safety fixtures independently evaluated by a third-party testing organization. Look for certification when selecting a compliant fixture. (Definitions)	Flush lines and test by activating weekly. Inspection tags are often included with fixtures to document testing and to satisfy a safety audit. (Sections 6.5.2, 8.2.1, 8.2.4.2)	ANSI recommends a comprehensive annual inspection of the facility to evaluate modified work space, assess new hazards introduced into the area, and to identify fixtures needing replacement or repair. (Sections 6.5.5, 8.2.4.5)

FREE Confidential Safety Evaluation • 800.BRADLEY • [bradleysafety.com](http://bradleysafety.com)



## Deck-Mounted Drench Hoses

### S19-460

Single vertical sprayhead

UL classified to meet ANSI/ISEA Z358.1 as a supplemental Eyewash only



S19-460

### S19-465

Single angled sprayhead

UL classified to meet ANSI/ISEA Z358.1 as a supplemental Eyewash only



S19-465

### S19-460EFW

Dual vertical sprayheads

UL classified to meet ANSI/ISEA Z358.1



S19-460EFW

### S19-465EFW

Dual angled sprayheads

UL classified to meet ANSI/ISEA Z358.1



S19-465EFW

## Wall-Mounted Drench Hoses

### S19-430A

Single vertical sprayhead

8' (2.4 m) yellow thermoplastic hose

UL classified to meet ANSI/ISEA Z358.1 as a supplemental Eyewash only



S19-430A

### S19-430D

Single vertical sprayhead

6' (1.8 m) flexible stainless steel hose

UL classified to meet ANSI/ISEA Z358.1 as a supplemental Eyewash only



S19-430D

## Retrofit Drench Hoses

### S19-430EH

Single head drench hose

Retrofits to most eye or eye/face wash fixtures

UL classified to meet ANSI/ISEA Z358.1 as a supplemental Eyewash only



S19-430EH

### S19-430SH

Single head drench hose

Retrofits to most drench showers or combination units

UL classified to meet ANSI/ISEA Z358.1 as a supplemental Eyewash only



S19-430SH



## Wall-Mounted Drench Hoses with Recoil Hose

### S1944011ABC

Dual vertical sprayheads  
ANSI-compliant eye/face wash  
12' (3.7 m) recoiling hose  
Squeeze handle activated  
UL classified to meet ANSI/ISEA Z358.1



S1944011ABC

### S1944011BBC

Dual angled sprayheads  
ANSI-compliant eye/face wash  
12' (3.7 m) recoiling hose  
Squeeze handle activated  
UL classified to meet ANSI/ISEA Z358.1

### S1944011CBC

Single vertical sprayhead  
12' (3.7 m) recoiling hose  
Squeeze handle activated  
UL classified to meet ANSI/ISEA Z358.1 as a supplemental Eyewash only



S1944011CBC

### S1944011CBD

Single vertical sprayhead  
25' (7.6 m) recoiling hose  
Squeeze handle activated  
UL classified to meet ANSI/ISEA Z358.1 as a supplemental Eyewash only

### S1944022ABC

Dual vertical sprayheads  
ANSI-compliant eye/face wash  
12' (3.7 m) recoiling hose  
Paddle activation handle  
UL classified to meet ANSI/ISEA Z358.1



S1944022ABC

## Back-flow Preventers

To select the appropriate back-flow preventer, check with local governing authorities on local codes and ordinances.

### S27-303

Dual check valve, Series 7



### S45-2310

Dual check vacuum breaker with intermediate atmospheric vent, Series 9D




### S45-2309

Dual check vacuum breaker with atmospheric vent, Series 9



### 140-226

Hose guide bracket  
Mounts under the deck to guide the hose







## Deck- and Wall-Mounted Eye and Eye/Face Washes

### Overview

A variety of laboratory fixtures are available to accommodate traditional and non-traditional installations. Elementary schools, hospitals, universities and research facilities equip their premises with these versatile, yet unique fixtures. Laboratory fixtures may be faucet, deck, wall, or counter-mounted. Bradley offers a diverse variety of fixtures to provide Eyewash solutions where space is restricted and safety is of the utmost importance.

### Key Features

- Chrome-plated brass pipe
- Paddle or push down handle activation
- ½" (13 mm) Inlet
- All items comply with ANSI/ISEA Z358.1

### Emergency Fixture Facts

The emergency fixture must be on the same level as the hazard. ANSI/ISEA Z358.1 Section 5.4.2

For additional safety products typically installed in laboratory applications, please consider:

Horizontal/Vertical Drench Showers	page 11
Pedestal-Mounted Eyewashes and Eye/Face Washes.	page 15
Wall-Mounted Eyewashes and Eye/Face Washes.	page 23

### Recommended Emergency TMV

#### Navigator EFX 8 (S19-2000)

The current ANSI standard calls for emergency Eyewashes and drench showers to deliver tepid water (60–100°F/15.5–37.7°C) for 15 minutes. A thermostatic mixing valve is needed to mix the hot and cold water supply. Bradley's Navigator TMVs are the most reliable emergency TMVs on the market. One valve is required per plumbed unit.





## Faucet-Mounted Eyewash

### S19-200B



One-step activation

Several adapters included

UL classified to meet ANSI/ISEA Z358.1

Lead-Free



S19-200B  
faucet not included

## Deck/Counter-Mounted Eyewash

### S19-260

Flush-mounted, stainless steel bowl with eye/face wash

Push-down activation handle

12<sup>7</sup>/<sub>8</sub>" (327 mm) stainless steel bowl

1<sup>1</sup>/<sub>4</sub>" (32 mm) waste

UL classified to meet ANSI/ISEA Z358.1



S19-260

### S19-270B

Stainless steel push handle

Eyewash swings 360 degrees

Right-hand activation

UL classified to meet ANSI/ISEA Z358.1



S19-270B

### S19-270BL

Stainless steel push handle

Eyewash swings 360 degrees

Left-hand activation

UL classified to meet ANSI/ISEA Z358.1

## Wall-Mounted

### S19-240

Eyewash

Yellow PVC push handle

UL classified to meet ANSI/ISEA Z358.1



S19-240

### S19-240FW

Eye/face wash

Yellow PVC push handle

UL classified to meet ANSI/ISEA Z358.1





## Recommended Emergency TMV

### Navigator EFX 8 (S19-2000)

The current ANSI standard calls for emergency Eyewashes and drench showers to deliver tepid water (60–100°F/15.5–37.7°C) for 15 minutes. A thermostatic mixing valve is needed to mix the hot and cold water supply. Bradley's Navigator TMVs are the most reliable emergency TMVs on the market. One valve is required per plumbed unit.



# Swing-Activated Eye and Eye/Face Washes

## Overview

Eyewash or eye/face wash fixtures that are swing activated are often located on lavatory decks that need to be available for a variety of different uses. A swing-activated fixture provides access to an ANSI-compliant fixture, while simultaneously making full use of valuable, yet limited space. Choose from a variety of wall-mounted or deck-mounted designs that swing out of the way when the fixture is in its resting position, but is still accessible for use during an emergency.

## Key Features

- Chrome-plated brass pipe
- Swing-down or swing-over activation controlled between two precise ceramic discs
- 20° activation and deactivation reduces splashing
- All items comply with ANSI/ISEA Z358.1
- Halo Eyewashes and eye/face washes provide the most wash down coverage available
- Halo dust cover caps on the Eyewash are hinged for a more secure hold — keeping dust and debris off the water spouts

## Emergency Fixture Facts

ANSI identifies a door as a barrier. ANSI/ISEA Z358.1, Appendix B5.

For additional safety products typically installed in laboratory applications, please consider:

Horizontal/Vertical Drench Showers	page 11
Pedestal-Mounted Eyewashes and Eye/Face Washes.	page 15
Wall-Mounted Eyewashes and Eye/Face Washes.	page 23
Standard and Explosion proof Signaling Systems	page 56–58






# Quick Compliance Guide

This guide serves as a supplement to the ANSI/ISEA Z358.1-2014 standard.

## Laboratory Eye & Face Wash Fixtures

- Valve mechanism opens in one second or less; it stays open until manually closed. (Sections 5.2, 6.2) ①
- Supply with flushing fluid, ("potable water, preserved water, preserved buffered saline solution or other medically acceptable solution...") (Definitions, Sections 5.1.1, 6.1.1)
- Locate 10 seconds or 55' (16.8 m) from contaminants or hazardous materials.
- Locate on same plane as the hazard, free of obstructions. (Sections 5.4.2, 6.4.2, Appendix B5)
- Protect unit heads from contaminants. (Sections 5.1.3, 6.1.3) ②
- Flow Rates: Eyewash unit delivers a minimum of .4 GPM for 15 minutes. (Section 5.1.6) Eye/face wash unit delivers a minimum of 3.0 GPM (11 L/Min) for 15 minutes. (Section 6.1.6)
- Use a flow meter to test flow rate; use a test gauge to test flow pattern. (Sections 5.1.8, 5.3.1, 6.1.7, 6.3)

The Joint Commission 2009 EC Standard for Hospitals requires: "The hospital takes action to minimize or eliminate identified safety and security risks in the physical environment." Furthermore, hospitals are required to "Minimize risk associated with selecting, handling, storing, transporting, using, and disposing hazardous chemicals." Surveyors commonly refer to OSHA requirements and the ANSI Standard for further guidance on best demonstrated practices.



## Top down view

Required to be free of obstructions a minimum of 6" (152 mm) from the outside of the eye or eye/face wash sprayheads.

(Sections 5.4.4, 6.4.4) ③

Use a Bradley test gauge (Model 269-1444) to check flow pattern. ④



15-minute Flush	Tepid Water	Third-Party Certifications	Weekly Activations:	Annual Inspections
Compliant fixtures release a continuous flow of tepid flushing fluid for a minimum of 15 minutes. (Sections 5.1.6, 5.4.5, 5.4.6, 6.1.6, 6.4.5, 6.4.6)	(lukewarm) 60–100°F (15.6–37.8°C) encourages full 15 minute flush or until medical personnel arrive. (Definitions, Sections 5.4.6, 6.4.6, Appendix B6)	Manufacturers may have their safety fixtures independently evaluated by a third-party testing organization. Look for certification when selecting a compliant fixture. (Definitions)	Flush lines and test by activating weekly. Inspection tags are often included with fixtures to document testing and to satisfy a safety audit. (Sections 5.5.2, 6.5.2)	ANSI recommends a comprehensive annual inspection of the facility to evaluate modified work space, assess new hazards introduced into the area, and to identify fixtures needing replacement or repair. (Sections 5.5.5, 6.5.5)

FREE Confidential Safety Evaluation • 800.BRADLEY • [bradleysafety.com](http://bradleysafety.com)



## Eyewashes

### S19274C



Deck/counter-mounted Eyewash

Durable, ceramic valve

Swings over sink for easy use

Universal right or left hand mounting options

UL classified to meet ANSI/ISEA Z358.1



S19274C

### S19274HD



Deck/counter-mounted Eyewash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



S19274HD

### S19274HDR



Reduced pipe length

Deck/counter-mounted Eyewash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



S19274HDR

### S19274HW



Wall-mounted Eyewash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



S19274HW

### S19274HDB




Deck/counter-mounted Eyewash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



S19274HDB

### S19274HWB



Wall-mounted Eyewash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1

### S19-270C

Deck/counter-mounted Eyewash

Durable, ceramic valve

Swings over sink for easy use

Universal right or left hand mounting options

UL classified to meet ANSI/ISEA Z358.1



S19-270C

### S19-270HD

Deck/counter-mounted Eyewash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



S19-270HD

### S19-270HW

Wall-mounted Eyewash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



S19-270HW

### S19-280D



Deck/counter-mounted Eyewash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



S19-280D

### S19-280W



Wall-mounted Eyewash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



## Eye/Face Washes

### S19274E



Deck/counter-mounted eye/face wash

Durable, ceramic valve

Swings over sink for easy use

Universal right or left hand mounting options

UL classified to meet ANSI/ISEA Z358.1



S19274E

### S19-270E

Deck/counter-mounted eye/face wash

Durable, ceramic valve

Swings over sink for easy use

Universal right or left hand mounting options

UL classified to meet ANSI/ISEA Z358.1



S19-270E

### S19274JD



Deck/counter-mounted eye/face wash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



S19274JD

### S19-270JD

Deck/counter-mounted eye/face wash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



S19-270JD

### S19274JDB



Deck/counter-mounted eye/face wash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



S19274JDB

### S19-270JW

Wall-mounted eye/face wash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



S19-270JW

### S19274JW



Wall-mounted eye/face wash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



S19274JW

### S19-290D



Deck/counter-mounted eye/face wash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1



S19-290D

### S19274JWB



Wall-mounted eye/face wash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1

### S19-290W



Wall-mounted eye/face wash

Durable, ceramic valve

Swings down over sink for easy use

UL classified to meet ANSI/ISEA Z358.1





## Recessed Drench Showers, Eye and Eye/Face Washes

### Overview

The recessed, corrosion-resistant, brushed stainless steel units offer a sleek, modern look. Frequently installed in hospitals, high schools, universities and laboratories, these fixtures maximize the space available. Many of the fixtures in this category include an integral drain pan, which collects the water run-off from the Eyewash and directs it into the drain, encouraging weekly activation. Halo eye or eye/face wash targets those areas of the body where a gentle spray of water is optimal.

### Key Features

- SpinTec showerhead improves water distribution
- Fixtures exceed ANSI-mandated flow rates
- Flush-mounted, corrosion-resistant, type 304 stainless steel cabinet
- Various modes of activation are available (fully recessed, surfacemounted or pull down handles)
- Swing down activation controlled between two precise ceramic discs
- All items comply with ANSI/ISEA Z358.1
- Halo Eyewashes and eye/ face washes provide the most washdown coverage available
- Halo dust cover caps on the Eyewash are hinged for a more secure hold, keeping dust and debris off the water spouts

### Emergency Fixture Facts

Emergency fixtures must be activated on a weekly basis and inspected annually. ANSI/ISEA Z358.1 Section 4.6.2, 5.5.2, 6.5.2, 7.5.5

### Suggested Accessories

Standard and Explosion-Proof Signaling Systems	page 56-58
--	------------

Drench Shower Testers	page 84
-----------------------	---------

Other parts and accessories are listed beginning on page 84

### Recommended Emergency TMV

#### Navigator EFX 25 (S19-2100)


The current ANSI standard calls for emergency Eyewashes and drench showers to deliver tepid water (60–100°F/15.5–37.7°C) for 15 minutes. A thermostatic mixing valve is needed to mix the hot and cold water supply. Bradley's Navigator TMVs are the most reliable emergency TMVs on the market. One valve is required per plumbed unit.





Barrier-Free, Recessed Drench Showers

S19-125BF



Fully recessed, push-down, coated stainless steel handle for quick and easy activation

Extended stainless steel shroud


UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-125BF

S19-125FMBF



Same features as S19-125BF, except with flush-mounted showerhead

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-125FMBF

S19-125SBF



Same features as S19-125BF, except with stainless steel plate to conceal ball valve

Surface-mounted, coated stainless steel handle for quick and easy activation

Extended stainless steel shroud


UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-125SBF

S19-125SFMBF



Same features as S19-125SBF, except with flush-mounted, showerhead

UL classified to meet ANSI/ISEA Z358.1

Listed by Intertek to EN 15154-1



S19-125SFMBF



## Cabinet-Mounted Swing-Down Eyewash

### S19284H



Activated when arm is pulled down

Wide access panel in front of unit for easy accessibility and serviceability

UL classified to meet ANSI/ISEA Z358.1



S19284H

### S19284J



Activated when arm is pulled down

Wide access panel in front of unit for easy accessibility and serviceability

UL classified to meet ANSI/ISEA Z358.1



S19284J

### S19284HB



Same features as S19284H, except barrier-free

UL classified to meet ANSI/ISEA Z358.1



S19284HB

### S19284JB



Same features as S19284J, except barrier-free

UL classified to meet ANSI/ISEA Z358.1



S19284JB

## Recommended Emergency TMV

### Navigator EFX 8 (S19-2000)

The current ANSI standard calls for emergency Eyewashes and drench showers to deliver tepid water (60–100°F/15.5–37.7°C) for 15 minutes. A thermostatic mixing valve is needed to mix the hot and cold water supply. Bradley's Navigator TMVs are the most reliable emergency TMVs on the market. One valve is required per plumbed unit.





## Barrier-Free, Cabinet Concealed Swing-Down Eyewash

### S19294HB



Concealed, cabinet-mounted Eyewash

Gas spring allows the door to descend in a smooth and controlled manner

Activated by opening the stainless steel door

Wide access panel in front of unit for easy accessibility and serviceability

Designed to mount in a 4" (102 mm) deep wall

UL classified to meet ANSI/ISEA Z358.1



S19294HB

### S19294HBT



Same features as S19294HB, except with P-trap

UL classified to meet ANSI/ISEA Z358.1

## Barrier-Free, Cabinet Concealed Swing-Down Eye/Face Wash

### S19294JB



Concealed, cabinet-mounted eye/face wash

Gas spring allows the door to descend in a smooth and controlled manner

Activated by opening the stainless steel door

Wide access panel in front of unit for easy accessibility and serviceability

Bottom-fed emergency TMV may be installed in maintenance compartment below fixture (recommended S19-2000EFX)

Designed to mount in a 6" (152 mm) deep wall

UL classified to meet ANSI/ISEA Z358.1



S19294JB

### S19294JBT



Same features as S19294JB, except with P-trap

UL classified to meet ANSI/ISEA Z358.1

## Recommended Emergency TMV

### Navigator EFX 8 (S19-2000)

The current ANSI standard calls for emergency Eyewashes and drench showers to deliver tepid water (60–100°F/15.5–37.7°C) for 15 minutes. A thermostatic mixing valve is needed to mix the hot and cold water supply. Bradley's Navigator TMVs are the most reliable emergency TMVs on the market. One valve is required per plumbed unit.

S19-2000EFX for use only with S19294JB and S19294JBT.





## Barrier-Free, Recessed Drench Shower and Eyewash

### S19345HXB



Extended, stainless steel shroud

Fully recessed, push-down, coated stainless steel handle

Wide access panel in front of unit for easy accessibility and serviceability

Gas spring allows the door to descend in a smooth and controlled manner

Designed to mount between a 4" (102 mm) wall

UL classified to meet ANSI/ISEA Z358.1



S19345HXB

## Barrier-Free, Recessed Drench Shower and Eye/Face Wash

### S19345JXB



Extended, stainless steel shroud

Fully recessed, push-down, coated stainless steel handle

Wide access panel in front of unit for easy accessibility and serviceability

Gas spring allows the door to descend in a smooth and controlled manner

Designed to mount between a 4" (102 mm) wall

UL classified to meet ANSI/ISEA Z358.1



S19345JXB

### S19345HXBT



Same features as S19345HXB, except with P-trap

UL classified to meet ANSI/ISEA Z358.1

### S19345JXBT



Same features as S19345JXB, except with P-trap

UL classified to meet ANSI/ISEA Z358.1

### S19345HFB



Same features as S19345HXB, except with flush-mounted showerhead

UL classified to meet ANSI/ISEA Z358.1

S19345HFB



### S19345JFB



Same features as S19345JXB, except with flush-mounted showerhead

UL classified to meet ANSI/ISEA Z358.1

S19-345JFBT



### S19345HFBT



Same features as S19345HFB, except with P-trap

UL classified to meet ANSI/ISEA Z358.1

### S19345JFBT



Same features as S19345JFB, except with p-trap

UL classified to meet ANSI/ISEA Z358.1

## Recommended Emergency TMV

### Navigator EFX 60 (S19-2200)

The current ANSI standard calls for emergency Eyewashes and drench showers to deliver tepid water (60–100°F/15.5–37.7°C) for 15 minutes. A thermostatic mixing valve is needed to mix the hot and cold water supply. Bradley's Navigator TMVs are the most reliable emergency TMVs on the market. One valve is required per plumbed unit.







### Drench Showerheads

Recessed flush-mounted showerhead provides smallest footprint in ceiling. For the most durable showerhead, select stainless steel which stands up to corrosion and aggressive impact.



### Eyewashes

When the safety risk targets the eye area, Bradley's Eyewashes are the recommended solution for emergency care. The Halo Eyewash sprayhead flows at approximately 5.1 GPM (19 L/Min), exceeding ANSI's 0.4 GPM (1.5 L/Min) flow rate. The flow gently flushes water directly on the eye to wash out contaminants.



### Eye/Face Washes

When chemicals and other hazardous liquids can contaminate the face and eyes, an eye/face wash is the solution. Bradley's Halo eye/face wash sprayhead features integral flow controls that provide a soft flush of approximately 5.1 GPM (19 L/Min). Eye/face washes are considered premium fixtures that exceed ANSI's 3.0 GPM (11 L/Min) mandate.



### Flow Controls

In the interest of water conservation, each shower head features an integral 20 GPM (76 L/Min) flow control. This item must be purchased separately for most competing brands.





## On-Site® Portable Gravity-fed Eyewashes

### Overview

The On-Site (S19-921) portable Eyewash is the most innovative gravity-fed Eyewash currently on the market. Employing a patented design, the On-Site is the only Eyewash on the market that uses just 7 gallons of water that provides a full 15-minute flush, at the ANSI-mandated flow rate and maintains a consistent height throughout the spray pattern until the last drop of liquid is depleted from the tank. The clear yellow polycarbonate tank offers an exclusive vandal-resistant design that makes worker safety a priority.

### Key Features

- Transparent tank allows solution level to be checked easily
- High-visibility yellow, molded pedestal and tank
- Vandal-resistant, patented design
- 7 gal/27 L (60 lbs/27 kg) provides full 15-minute flush
- Heater jacket available to prevent freezing
- Complies with ANSI/ISEA Z358.1
- One-year warranty

### Emergency Fixture Facts

ANSI requires the visual inspection of self-contained Eyewashes to be certain the tank is full and ready for use. ANSI/ISEA Z358.1 Section 5.5.3

**Ideal for locations where a plumbed water source is not available.**



# Quick Compliance Guide

This guide serves as a supplement to the ANSI/ISEA Z358.1-2014 standard.




## Self-Contained Eyewash Fixtures

- Eyewash unit delivers a minimum of .4 GPM for 15 minutes. (Section 5.3.2)
- Valve mechanism opens in one second or less; it stays open until manually closed. (Section 5.3.2)
- Supply with flushing fluid, ("potable water, preserved water, preserved buffered saline solution or other medically acceptable solution...") (Definitions, Section 5.1.1)
- Locate 10 seconds or 55' (16.8 m) from contaminants or hazardous materials. Locate on same plane as the hazard, free of obstructions. (Sections 5.4.2, Appendix B5)
- Use a test gauge to test flow pattern. (Section 5.4.7)
- Frigid conditions require the installation of freeze protection equipment. (Section 5.4.5) ①

## Top down view

Required to be free of obstructions a minimum of 6" (152 mm) from the outside of the Eyewash sprayheads. (Sections 5.4.4) ②

Use a Bradley test gauge (Model 269-1444) to check flow pattern. ③



Front View



Distance to floor  
33-53" (838-1346 mm)  
(Sections 5.4.4, 6.4.4)

15-minute Flush	Tepid Water	Third-Party Certifications	Weekly Activations:	Annual Inspections
Compliant fixtures release a continuous flow of tepid flushing fluid for a minimum of 15 minutes. (Sections 5.1.6, 5.4.5, 5.4.6)	(lukewarm) 60-100°F (15.6-37.8°C) encourages full 15 minute flush or until medical personnel arrive. (Definitions, Sections 5.4.6, Appendix B6)	Manufacturers may have their safety fixtures independently evaluated by a third-party testing organization. Look for certification when selecting a compliant fixture. (Definitions)	Flush lines and test by activating weekly. Inspection tags are often included with fixtures to document testing and to satisfy a safety audit. (Sections 5.5.2)	ANSI recommends a comprehensive annual inspection of the facility to evaluate modified work space, assess new hazards introduced into the area, and to identify fixtures needing replacement or repair. (Sections 5.5.5)

FREE Confidential Safety Evaluation • 800.BRADLEY • [bradleysafety.com](http://bradleysafety.com)



## On-Site® Portable Gravity-fed Eyewash

### S19-921

Hinged Eyewash tray activates in one quick motion

Stainless steel clamps secure the tank during transport

Vandal-resistant unit; foreign objects cannot be introduced into tank because all openings are sealed once the tank is installed

7 gal (27 L) tank is one of the lightest portable Eyewashes on the market

Wall bracket (can also deck mount)

UL classified to meet ANSI/ISEA Z358.1



S19-921

## On-Site Heater Jacket Retrofit Kit

### S19-921HR

Heater jacket ships attached to tank

No tools required

## On-Site Waste Cart

### S19-399

High-visibility yellow

Captures used fluid, 56 gal (212 L) capacity

Tapered sump, easy to drain



S19-399

## On-Site Eyewash and Heater Jacket

### S19-921H

Protects against freezing; down to -10°F (-23.3°C)

Insulated heater jacket conceals a 121-watt heater

Secondary thermostat prevents overheating if primary thermostat fails

Requires 120-volt AC line

UL classified to meet ANSI/ISEA Z358.1



S19-921H

## On-Site Water Eyewash Kit

### S19-949

Replacement cap

Nine liners

Inspection tag



S19-949

## On-Site Transparent Tank

### 133-140

Replacement 7 gal (27 L) tank

Sold individually



133-140

## On-Site Foam Liner

### 269-1379

Perforated foam liner

Sold individually





# Portable Pressurized Eyewashes

## Overview

Looking for a portable Eyewash that will withstand corrosive materials in isolated locations, can be used on trucks or areas without plumbing that require a 15-minute flush? Bradley's stainless steel portable pressurized tanks resist corrosion, and offer several options for customers that are looking for an Eyewash with a drench hose, or even a tank outfitted with a heater jacket to prevent freezing. Portable pressurized tanks are a versatile, corrosion-resistant solution, to provide an ANSI-compliant fixture in remote or non-plumbed locations. Portable pressurized fixtures balance the volume of water with a predetermined amount of pressure to maximize the time and volume of solution that provides a flush. The portable pressurized Eyewash offers the convenience of a portable unit, is sold in a range of sizes, and the heater jacket option offers flexibility to handle a wide range of applications.

## Key Features

- Built-in carrying handles
- Tire filler valve with 0 – 160 psi (1103 kPa) air gauge
- Pressure relief valve to prevent over pressurization
- 8' (2.4 m) drench hose (unless otherwise specified)
- Chrome-plated brass Eyewash
- All items comply with ANSI/ISEA Z358.1

## Emergency Fixture Facts

ANSI guidelines require that emergency fixtures supply potable water, preserved water, preserved buffered saline solution, or an alternative medically accepted solution.

ANSI/ISEA Z358.1 Section 3, Definitions



## 5 gal (19 L) Units

- Eyewash flow: 8 minutes
- Drench hose flow: 2.5 minutes
- Meets ANSI criteria as a personal wash station only

### S19-670

Drench hose, no Eyewash

### S19-671

Eyewash only, no drench hose

### S19-671H

Jacket prevents freezing

280-watt heater

Eyewash only

### S19-672

Eyewash with drench hose



S19-671



S19-672

## 10 gal (39 L) Units

- Eyewash flow: 15 minutes
- Drench hose flow: 3.5 minutes
- UL classified to meet ANSI/ISEA Z358.1

### S19-690

Eyewash with drench hose

### S19-690LHS

Eyewash only, no drench hose

### S19-690H

Jacket prevents freezing

510-watt heater

Eyewash only



S19-690LHS



S19-690H

## 15 gal (57 L) Units

- Eyewash flow: 18 minutes
- Drench hose flow: 5 minutes
- UL classified to meet ANSI/ISEA Z358.1

### S19-788

Eyewash and drench hose

### S19-788LHS

Eyewash only, no drench hose

### S19-788H

Jacket prevents freezing

510-watt heater

Eyewash only



S19-788



## Heater Jacket Retrofit Kits for Portable Pressurized Eyewashes

### S19-671HR

Jacket for 5 gal (19L) tank

### S19-690HR

Jacket for 10 gal (39 L) tank

### S19-788HR

Jacket for 15 gal (57 L) tank

## Optional Cart

### S19-690A

Four-wheel, stainless steel transport cart

For use with fixtures without a heater jacket



S19-690A

## On-Site Heater Jacket Retrofit Kit

### S19-921HR

Heater jacket ships attached to tank

No tools required

## On-Site Waste Cart

### S19-399

High-visibility yellow

Captures used fluid, 56-gallon capacity

Tapered sump, easy to drain



S19-399

## Drench Hose Spray Kits

Includes all necessary fittings and hanger for attaching hose to Bradley units to provide a body water drench

### S19-430EH

Drench hose spray kit that attaches to eyewashes



S19-430EH

### S19-430SH

Drench hose spray kit for use with drench showers



S19-430SH

## Privacy Curtain

### S19-330

Universal mounting

Waterproof, 3-ply reinforced vinyl laminate

Chemical and mildew resistant

Curtain Color: high-visibility yellow  
Dimensions: 70"x 145" (1778 x 3683 mm)

Curtain rail and mounting brackets Stainless steel corrosion resistant Rail dimensions: 1½" x 42" diameter

For a model compatible with barrier-free fixtures, contact Bradley for more information

Not compatible with PVC or heat trace units



S19-330

## Drench Shower Tester

### S19-330ST

Heavy-duty tester for required weekly activation

Water-tight funnel with weighted bottom

Dimensions: 84" (2134 mm) long

8' (2.4 m) telescoping aluminum handle



S19-330ST



**S19-322 Series****S19-322E**

UL listed 1/2" (32mm) flow switch  
 NEMA 1 signaling system  
 Universal AC Input: 90-264 AC  
 Flashing amber LED signal light  
 For eye or eye/face washes

**S19-322D**

UL listed 1 1/4" (32mm) flow switch  
 NEMA 1 signaling system  
 Universal AC Input: 90-264 AC  
 Flashing amber LED signal light  
 For drench showers or combination units

**S19-323 Series****S19-323E**

UL listed 1/2" (13 mm) brass flow switch  
 NEMA 3R signaling system  
 6' (1.8 m) Cable  
 For eye or eye/face wash  
 Universal AC Input: 90-264 AC  
 Amber signal light

**S19-323D**

UL listed 1 1/4" (32mm) brass flow switch  
 NEMA 3R signaling system  
 6' (1.8 m) Cable  
 For drench shower or combination units  
 Universal AC Input: 90-264 AC  
 Amber signal light

**S19-324 Series****S19-324E**

Brass UL listed 1/2" (13mm) flow switch  
 NEMA 4X signaling system  
 6' (1.8 m) Cable  
 For eye or eye/face wash  
 Silence switch with auto reset  
 Universal AC Input: 90-264 AC  
 Amber signal light

**S19-324D**

Brass, UL listed 1 1/4" (32 mm) flow switch  
 NEMA 4X signaling system  
 6' (1.8 m) Cable  
 For drench showers or combination units  
 Silence switch with auto reset  
 Universal AC Input: 90-264 AC  
 Amber signal light

**S19-324DG, S19-324DGW**

Brass UL listed 1 1/4" (32 mm) flow switch  
 NEMA 4X signaling system  
 6' (1.8 m) Cable  
 Silence switch with auto reset  
 Green beacon light  
 White area light (S19-324DGW only)  
 For drench showers or combination units  
 Universal AC Input: 90-264 AC  
 Amber signal light





## S19-324 Series continued

### S19-324EG, S19-324EGW

- UL listed 1/2" (13mm) brass flow switch
- NEMA 4X signaling system
- 6' (1.8 m) Cable
- Silence switch with auto reset
- Green beacon light
- White area light (S19-324EGW only)
- For eye wash or eye/face washes
- Universal AC Input: 90-264 AC
- Amber signal light



## Explosion-Proof Emergency Signaling System (Class 1 Division 2, Groups B, C & D)

### S19-324D2D/HT

- NEMA 4X
- Brass UL listed 1 1/4" (32 mm) flow switch
- For drench shower or combination units
- Amber signal light
- S19-324D2DHT for S19-304 heat traced combination units



## Explosion-Proof Emergency Signaling System (Class 1 Division 1, Groups C & D)

### S19-324D1D/HT

- NEMA 4X
- Brass UL listed 1 1/4" (32 mm) flow switch
- For drench shower or combination units
- Amber signal light
- S19-324D1DHT for S19-304 heat traced combination units



## Freeze and Scald Protection Valves

Bradley's freeze and scald protection valves coupled with Navigator tempering systems serve an important role. Although the tempering system supplies the fixture with tepid water, environmental conditions may cause the water to freeze or become scalding hot. To ensure the fixture is ready to use and the water is safe for your employees at all times, consider the addition of a freeze or scald protection valve, to bleed off water in extreme temperatures.

## Freeze Protection Valve Kits

### S45-1986

For use with Eyewashes



### S45-1987

For use with drench showers



\* Classic combination fixtures require one each of S45-1986 and S45-1987. Halo combination fixtures only require one S45-1986.

## Scald Protection Valve Kits

### S45-1989

For use with Eyewashes



### S45-1990

For use with drench showers



\* Classic combination fixtures require one each of S45-1989 and S45-1990. Halo combination fixtures only require one S45-1989.

Don't see the signaling system you are looking for? Go to page 60-62 to use the S19-324 Configurator



## Eyewash Handle, Ball Valve and Hardware

### S30-070

Stainless steel handle

Hardware

1/2" (13 mm) NPT stay-open ball valve



S30-070

### S30-072

Stainless steel handle

Hardware

1/2" (13 mm) NPT stay-open ball valve

For stainless steel hinged dust covers only

### S30-074

Left-hand activation conversion kit for pedestal-mounted or combination fixtures

Stainless steel handle

Hardware

1/2" (13 mm) stay-open ball valve

### S45-122

Plastic handle

Hardware

1/2" (13 mm) NPT stay-open ball valve



S45-122

## Eyewash Handle, Ball Valve and Hardware Only

### 128-135

Plastic handle only

### S08-336

Stainless steel handle only

Vertical valve applications only

### S08-338

Stainless steel handle only

Horizontal valve applications only

### S30-075

Left-hand activation conversion kit for pedestal-mounted or combination fixtures

Stainless steel handle

Hardware

For S19-270BL Eyewash only

### S30-087

Stainless steel handle

Hardware

For stainless steel hinged dust covers only

### S45-123

Plastic handle

Hardware

### S30-071

Stainless steel handle

Hardware



## Eyewash Ball Valves Only

### S27-282

Brass ½" NPT stay-open ball valve only

### S27-287

Stainless steel ½" NPT stay-open ball valve only

## Sprayhead and Spray Ring Assemblies

### S45-2453

Includes orange flow control

2.4 GPM (9 L/Min) flow control inside each head; total flow from both heads is 4.8 GPM (18 L/Min)

Eye/face wash sprayheads only



S45-2453

### S39-394

Eyewash head assembly with supply stem



S39-394

### S39-396

Eye/face wash sprayhead assembly with supply stem



S39-396

### S39-681

Eye/face wash sprayhead assembly

Stem not included

### S39-682

Eye/face wash assembly

For use with PVC unit only

Stem not included

### S05-127

Spray ring only

Can only be added to Eyewash with cross-connection yoke

### S39-397

Eyewash and spray ring assembly with supply stem



S39-397

## Dust Caps

### 107-371

Dust caps only

Sold individually; two required per Eyewash

Approximately 1" (25 mm) x 1" (25 mm)

Yellow plastic tether



107-371

### S53-063

Dual eye/face wash dust caps only

Sold individually; two required per Eyewash

2¼" (57 mm) x 1" (25 mm)

Beaded chain tether



S53-063

### S53-310

Eyewash dust cap

Sold individually; two required per Eyewash

1" (25 mm) x 1" (25 mm)

Not for use with portable pressurized tank Eyewashes



S53-310



## Bowls

### 154-058

10" (254 mm) diameter impact-resistant plastic Eyewash bowl



154-058

### 187-053

10 3/4" (273 mm) diameter stainless steel Eyewash bowl



187-053

## Stem Spacers

### 113-1159

Stainless steel stem spacer

For use in fixtures with stainless steel bowl



113-1159

### 113-1185

Black plastic stem spacer

For use in fixtures with yellow plastic bowl



113-1185

## Stem Assemblies

### Eyewash Fixtures Only

S21-071 Brass

S21-072 SS304



S21-071

### Eyewash with Spray Ring Fixtures Only

S21-073 Brass

S21-074 SS303

S21-075 SS316

### 113-1150

Brass stem only: for units with dual black eye/face heads

### 113-1151

Stainless steel stem only: for stainless steel units with dual black eye/face wash heads

## Classic Stem Assemblies

Sprayhead Assembly	Galvanized Fixture with Plastic Bowl	Galvanized Fixture with Stainless Steel Bowl	Standard Stainless Steel Fixture	316 Stainless Steel Fixture
Eyewash Only	S21-071 113-1185	S21-071 113-1159	S21-072 113-1159	S21-075 113-1159
Eye/Face Wash with Spray Ring	S21-073 113-1185	S21-073 113-1159	S21-074 113-1159	None
Eye/Face Wash w/ Dual Black Heads	113-1150	113-1150	113-1151	None

Spacer 113-1159 or 113-1185 is required for units that shipped on or before 11/2/2005.

Assemblies include stem and appropriate flow control.

Stems S21-036 and S21-050 are obsolete.

## Eyewash and Eye/Face Wash Flow Restrictors

### 125-167

3.7 GPM (14 L/Min) flow restrictor

Pink

For Eyewash with face spray ring

Stem not included



125-167

### 125-032

3.5 GPM (13 L/Min) flow restrictor

Black

For swing activated or swing-down units



## Replacement Parts – Halo

**187-320**

Plastic bowl



187-320

**S05-190**

Sprayhead assembly



S05-190

**S05-192**

Sprayhead assembly



S05-192

**S05-204**

304 stainless steel sprayhead assembly



S05-204

**S05-205**

316 stainless steel sprayhead assembly



S08-390

**S08-390**

Handle kit



S27-327

**S27-327**

Chrome-plated 1/2" ball valve



S27-328

**S27-328**

Stainless Steel 1/2" ball valve

**S45-2675**

Eyewash cover kit



S45-2675

**S45-2676**

Eye/Face wash cover kit



S45-2676

**S65-339**

O-ring and screen



S65-339

**S88-068**

O-ring screen and flow control



S88-068

**S90-388**

Stainless steel bowl cover kit



S90-388

**S90-390**

Plastic bowl cover kit



S90-390

**S90-391**

Stainless steel bowl kit



S90-391

**S90-392**

Stainless steel bowl kit

316 stainless steel



## Retrofit Classic Dust Covers

### S45-1964

Compatible with any Bradley classic Eyewash bowl

Fixture not included



S45-1964

### S45-2396

For use with any Bradley classic Eyewash bowl

Includes welded stainless steel clam shell cover, stainless handle with teather and quick release pin




S45-2396

## Drench Shower Handle for Standard Units

### 128-156A

25½" (648 mm) pull rod only

Standard pull rod shipped with non-barrier-free showers



128-156A

### 128-156B

36" (914 mm) pull rod only

## Drench Shower Handle for Barrier-Free Units

### 128-156C



48" (1219 mm) pull rod only

### 128-156D



45½" (1156 mm) pull rod only

Standard pull rod shipped with barrier-free showers

### 128-156E



57" (1448 mm) pull rod only

### 128-156F



69" (1753 mm) pull rod only



128-156D

## Drench Shower Handle for Heat Trace Units

### 128-156G

27" (686 mm) pull rod only



## SpinTec Showerhead Retrofit Kits

Universal retrofit kits include all items shown

### S24-192

Ornamental plastic shroud with ring – showerhead nozzle not included



S24-192

### S24-202

In-ceiling recessed showerhead assembly, with 5 $\frac{7}{8}$ " (149 mm) white steel shroud, includes 90° elbow



S24-202

### S24-193

Ornamental stainless steel shroud with ring – showerhead nozzle not included



S24-193

### 154-147

Ring only



154-147

### S24-194

Showerhead nozzle and 90° elbow



S24-194

## Drench Shower Ball Valve

### S27-276

Stainless steel 1" (25 mm) ball valve only



S24-195

### S27-278

Chrome-plated brass 1" (25 mm) ball valve only



S24-196

### S24-196

Ornamental stainless steel shroud with ring, showerhead nozzle and 90° elbow



S24-196

### S30-059

Chrome-plated brass 1" (25 mm) ball valve with lever



S30-059

### S24-200

304 Stainless steel showerhead and 90° elbow



S24-200

### S30-061

Stainless steel 1" (25 mm) ball valve with lever



## Self-Closing Ball Valve

### S19-0011

Note: Self-closing ball valves are not ANSI/ISEA Z358.1 compliant. Appendix B3. However, an exception may be made in a "school laboratory situation." Contact local authorities regarding specific application.

## Drench Hose Replacement Part Valves

### S39-817

Replacement valve with drench hose sprayhead



S39-817

## Hoses

### S89-002

8' (2.4 m) yellow thermoplastic hose



S89-002 & S89-003

### S89-003

6' (1.8 m) stainless steel hose

### 269-053

12' (3.7 m) yellow thermoplastic hose

Recoiling

### 269-054

25' (7.6 m) yellow thermoplastic hose

Recoiling

## Hose Guide Bracket

### 140-226

Drench hose guide bracket

For deck-mounted applications



140-226

## Hose Spray Valve

### S27-265

Replacement valve only

## Back-flow prevention

### S27-303

Dual check valve, Series 7



S27-303

### S45-2309

Dual check vacuum breaker, Series 9



S45-2309

### S45-2310

Dual check vacuum breaker with intermediate atmospheric vent, Series 9D



S45-2310



## Safety Signs

**114-050**

Drench shower sign



114-050

**114-051**

Eyewash sign



114-051

**114-052**


Combination shower and  
Eyewash sign



114-052

**114-050E**

International safety drench  
shower sign



114-050E

**114-051E**

International safety Eyewash sign



114-051E

**114-052E**

International safety combination  
drench shower and Eyewash sign



114-052E

## On-Site Water Eyewash Kit

**S19-949**

Replacement cap

Nine liners

Inspection tag



S19-949

## On-Site Foam Liner

**269-1379**

Perforated foam liner

Sold individually

## Gravity Fed Tank

**133-140**

Seven gallon tank



133-140

## Miscellaneous Supplies

**269-964**

Safety yellow touch-up paint

12-oz. aerosol



269-964

**204-421**

Inspection tag

Sold individually



204-421

**269-1444**

Eyewash test gauge



269-1444



## Foot Treadle Kits

### S39-395

Includes all necessary fittings for attaching to wall-mounted Eyewashes for hand or foot operation



S39-395

### S45-572

Includes all necessary fittings for attaching to Bradley pedestal-mounted Eyewashes and combination showers for hand or foot operation



S45-572

### S45-620

Same as S45-572, except designed for S19-310PVC shower only

### S45-1314SS

Stainless steel type 316 foot treadle that includes all necessary type 304 fittings for attaching to Bradley pedestal-mounted Eyewashes and combination showers/Eyewashes for hand or foot operation

### S45-1314SS16

Stainless steel type 316 foot treadle that includes all necessary type 316 fittings for attaching to Bradley pedestal-mounted Eyewashes and combination showers/Eyewashes for hand or foot operation

## Optional Adapters

### 153-395

Female,  $\frac{13}{16}$ " (21 mm) x 24—Chrome

### 153-396

Male,  $\frac{3}{8}$ " (10 mm) NPSM—Chrome

### 153-401

Female,  $\frac{3}{4}$ " Garden Hose—Chrome



## Standard Specifications

### Halo S19214, S19224 & S19314 Series

#### Eyewash Bowl

14" (356 mm) corner to corner, yellow impact-resistant plastic, Type 304 corrosion-resistant stainless steel or Type 316 corrosion-resistant stainless steel

#### Sprayhead Assembly

All sprayhead assemblies include flow control to assure safe, steady water flow under varying water supply conditions (up to 90 PSI) and flip-top protective spray covers

#### Halo Eyewash

- ABS plastic soft-flow sprayheads designed to gently cleanse the eyes
- Exceeds minimum water flow: 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)
- Flip-open dust covers that open automatically when unit is activated
- Self-draining design eliminates standing water

#### Halo Eye/Face Wash

- ABS plastic soft-flow sprayheads designed to gently cleanse the eyes and face
- Exceeds minimum water flow: 3.0 GPM (11 L/Min) at 30 psi (207 kPa)
- Flip-open dust covers that open automatically when unit is activated
- Self-draining design eliminates standing water

#### SpinTec Showerhead

- 3.1" (79 mm) diameter
- Uniform distribution of water
- Integral flow control provides a minimum of 20 GPM (76 L/Min)

#### ANSI Compliance

Unless otherwise indicated, all units comply with the ANSI/ISEA Z358.1 standard

#### Eyewash Valve

1/2" stay-open eye and eye/face wash valve manufactured of the following materials and supplied with either type 304 or 316 stainless steel handle that can be activated from both the left and right side of the unit

- Chrome-plated brass
- Type 316 stainless steel

#### Shower Valve

1" (25 mm) stay-open eye and eye/face wash valve manufactured of the following materials and supplied with either type 304 or 316 stainless steel pull rod

- Chrome-plated brass
- Type 316 stainless steel

#### Pipe and Fittings

- 1 1/4" piping assembly manufactured of one of the following materials
- Galvanized steel with BradTect safety yellow coating
- Type 304 corrosion-resistant stainless steel
- Type 316 corrosion-resistant stainless steel
- Chrome-plated red brass.

#### Water Supply

Wall-mounted and pedestal-mounted: 1/2" NPT female

#### Waste

Eyewash: 1 1/4" NPT female drain fitting

#### Transparent Plastic or Stainless Steel Dust Cover

- Protects entire bowl to keep contaminants, dust, and other debris from Eyewash area
- Dust cover opens when push handle is activated
- Constructed of transparent yellow impact-resistant plastic, type 304 corrosion-resistant stainless steel or type 316 corrosion-resistant stainless steel.

#### Additional Features

- **Eyewash mounting**  
Heavy-gauge aluminum with four clearance holes for wall mounting (hardware not included)  
All units are barrier free when mounted at the correct height
- Separate supply and waste, eliminates cross contamination risk
- Contains an antimicrobial agent to protect the sprayhead
- UL recognized to meet the ANSI/ISEA Z358.1 Standard



## Standard Specifications

### Classic Models

(exceptions noted)

#### Eyewash Bowl

10" (254 mm) diameter, yellow, impact-resistant plastic or corrosion-resistant stainless steel

#### Sprayhead Assembly

All sprayhead assemblies include flow control to assure safe, steady water flow under varying water supply conditions (up to 90 psi/621 kPa) and pop-off protective spray covers

- **Eyewash**

Chrome-plated brass, soft-flow sprayheads designed to gently cleanse the eyes – stainless steel where specified  
Exceeds minimum water flow: 0.4 GPM (1.5 L/Min) at 30 psi (207 kPa)

- **Eye/Face Wash, Dual Sprayheads**

Contains an antimicrobial agent to protect the sprayhead  
ABS plastic perforated disc sprayheads designed to gently cleanse the eyes and face  
Exceeds minimum water flow: 3.0 GPM (11 L/Min) at 30 psi (207 kPa)

- **Face Spray Ring**

Chrome-plated, circular spray ring designed with a wider spray pattern for full face spray

#### SpinTec Showerhead

- Yellow, impact-resistant plastic or corrosion-resistant stainless steel
- 3.1" (79 mm) diameter
- Uniform distribution of water
- Integral flow control provides a minimum of 20 GPM (76 L/Min)

#### Drench Hose

- 8' (2.4 m) yellow, reinforced thermoplastic hose (unless otherwise specified)
- 450 PSI burst strength
- Recoiling hose (where specified) retracts for storage while allowing easy extension in emergency situations

#### ANSI Compliance

Unless otherwise indicated, all units comply with the ANSI/ISEA Z358.1 standard

## Drench Hose Series S19-430 through S19-630 Specifications

#### Drench Hose Valve

Chrome-plated valve with extended reinforced handle remains open once handle is squeezed.

- S19-630: Uses a ½" (13 mm) NPT chrome-plated brass, stay-open ball valve operated by a stainless steel push handle

#### Water Supply

Drench hoses: ¾" (10 mm) NPT male thread with removable ½" NPT female reducing coupling

## Series S19-921 On-Site® Gravity-Fed Eyewashes

#### On-Site Gravity-Fed Eyewash

Can be mounted on a wall or deck. Stainless steel bracket included for wall mounting. Molded handle design for easy transportability. Should be placed in a fixed location when completely assembled and filled with fluid.

- Seven-gallon fill capacity
- Easy to clean, refill, and check solution
- Meets 15-minute minimum flushing requirement at 0.4 GPM
- Transparent yellow, polycarbonate tank – visual reminder when it is time to clean or refill the tank
- Blow-molded design prevents leakage
- Opaque yellow, polypropylene pedestal with hinged Eyewash tray
- Eyewash tray pulls down in one quick motion – water flow is activated by this motion
- Removable tank is inverted onto the pedestal, piercing a liner
- Weighs 23 lbs (10 kg) when empty and 60 lbs (27 kg) filled

#### On-Site Waste Cart

Utilized with the Gravity-Fed Eyewash product.

- High-visibility yellow, polyethylene with 56 gal (212 L) capacity
- Captures used fluid from unit
- Tapered sump allows for easy drainage

#### Gravity-Fed Heater Jacket

- 121-watt heater enclosed in an insulated jacket
- Secondary thermostat with warning light and manual reset button helps prevent overheating in case of primary thermostat failure
- Requires 120-volt AC line
- All UL-listed components



## Drench Shower Series S19-110 thru S19-130 and Combination Units Series S19-310 Shower Specifications

### Shower Valve

1" (25 mm) NPT chrome-plated brass, stay-open ball valve operated by a stainless steel pull rod with triangular handle.

- Barrier-free pull rod extends to 48" from floor
- S19-130F and S19-120G Cord operated with self-closing ball valve  
Not compliant with ANSI/ISEA Z358.1

### Pipe and Fittings

Standard: Galvanized steel pipe protected with BradTect yellow coating (unless otherwise specified).

- Vertical/horizontal shower: 1" (25 mm) pipe
- Freestanding shower, combination units: 1¼" pipe
- PVC combination shower: 2" (51 mm) Schedule 80

### Water Supply

- Vertical/horizontal shower: 1" (25 mm) NPT female
- Freestanding shower, combination and barrier-free units: 1¼" NPT female

## Drench Showers Series S19-120HFP; Eyewash Series S19-220HFP; Combination 310TW Frost-Proof Units

### Eyewash Bowl/Sprayhead/Showerhead

See standard specifications

### Through Wall Units

- Standard option is 8–12" (203–305 mm) wall thickness
- 0–8" (0–203 mm) and 12–18" offered as special orders

### Valve

1" (25 mm) NPT chrome-plated brass, stay-open ball valve is hand operated by a stainless steel handle

### Pipe and Fittings

1¼" galvanized steel pipe protected by BradTect yellow coating (unless otherwise specified)

### Water Supply

- ½" (13 mm) NPT female (model S19-220HFP)
- 1" (25 mm) NPT female (model S19-120HFP)
- 1¼" (32 mm) NPT female (all other models)

## Eyewash Series S19-200 thru S19-270JC; Combination Units Series S19-310 Plumbed Eyewash Specifications

### Eyewash Valve

½" NPT chrome-plated brass, stay-open ball valve operated by a high-visibility yellow PVC or stainless steel (where specified) push handle.

#### • **Faucet-mounted unit**

Activates when water is turned on at faucet and activator pin on Eyewash is pulled toward user

Applied water pressure keeps activator pin open

Faucet will maintain normal operation for hand washing, etc. when activator pin is closed

#### • **Swing-activated units (where indicated):**

The swinging motion of the unit operates Eyewash valve – no additional handle is required

### Pipe and Fittings

Standard: Galvanized steel pipe protected with BradTect yellow coating (unless otherwise specified); laboratory and swing-activated units are primarily chrome-plated brass.

- Wall-mounted Eyewash, laboratory Eyewash: ½" pipe
- Pedestal Eyewash: 1¼" pipe

### Water Supply

- Wall-mounted, pedestal-mounted, swing-activated Eyewash  
½" NPT female
- Laboratory: ½" NPT (unless otherwise specified)

### Waste

Eyewash: Dome-type strainer and 1¼" NPT female drain fitting with tailpiece (P-trap to conform to local codes by others unless otherwise specified)

### Hinged Stainless Steel Dust Cover

- Protects entire bowl to keep contaminants, dust, and other debris from Eyewash area
- Dust cover springs open when push handle is activated



## Additional Features

- **Eyewash wall bracket**  
Heavy-gauge aluminum with three clearance holes for wall mounting (hardware not included)  
Barrier-free unit is stainless steel with four clearance holes for wall mounting
- **S19-220BF stainless steel, wrap-around skirt:**  
10" diameter corrosion-resistant stainless steel  
Conceals plumbing – unit extends 20" from wall

## Series S19-304 Heat Traced Showers

### Showerhead/Sprayheads

See standard specifications

### Shower Valve

1" (25mm) NPT chrome-plated brass, or 316 stainless steel, stay-open valve is operated by a stainless steel pull rod with triangular handle

### Eyewash Valve

1/2" NPT chrome-plated brass, or 316 stainless steel, stay-open valve hand operated by a stainless steel handle

### Pipe and Fittings

1 1/4" galvanized steel, 304 stainless steel, or 316 stainless steel.

### Electric Heat Trace Cable\*

- Wraps around pipe, cable is self-regulated to 50°F (10°C) to protect against overheating and cold spots
- Thermal rating: 5 watts/foot
- Service voltage: 120-volt AC or 240-volt AC
- Amperage/wattage: .7 amp/80 watts at 50°F (10°C) unit water temperature

### Pipe Insulation

- 3/4" polyethylene closed cell encases pipe and heat trace cable
- Vertical semi-split allows insulation to be easily removed and re-assembled

### Protective Outer Shell

- UV-stabilized ABS plastic
- Six easy-to-remove sections
- Designed for quick repairs and maintenance
- Sealed with rivets for added weather protection
- Resists chemical and other harsh environments

## Freeze Protection Valve

- Continual flow of water when internal temperatures drop below 35°F (2°C)
- Valve closes at 45°F (7°C)
- Max pressure rating of 200 psi (1379 kPa)

## Thermostat\*

Opens at 64°F (18°C) and closes at 54°F (12°C)

## Junction Box

General area junction box is plastic with one extra 3/4" conduit hole. Hazardous location junction boxes are aluminum with multiple hubs. Accepts 3/4" IPS conduit.

## Water Supply

- 1 1/4" (44 mm) NPT male top or bottom supply

\* Standard specification components are rated for General Area, Class 1 Division 2 Groups B, C, and D, Class 1 Division 1 Groups C and D, and Class II Division 1 and 2 Groups E, F, C and G. All units are CSA listed.

## Series S19-670 thru S19-788 Pressurized Stainless Steel Eyewash Tanks

### Eyewash Sprayhead/Drench Hose

- See standard specifications
- Available in 5 gal (19 L), 10 gal (39 L) and 15 gal (57 L) capacities. Built-in carrying handles and resilient bottom. Tire filler valve with 0-160 PSI (0-1100 kPa) air gauge. Pressure relief valve prevents accidental over pressurization.

NOTE: Do not exceed 130 PSI tank pressurization.

### Portable Heated Units

- Secondary thermostat with manual reset button helps prevent overheating in case of primary thermostat failure
- Plugs into any 120-volt AC line
- All UL listed components.
- 10 gal (39 L) and 15 gal (57 L) units provide 15 minutes of tempered water flow from Eyewash
- GFCI recommended



## Halo vs. Classic Cross Reference Model Numbers

Product	Classic Model No.	New Halo No.
<b>Pedestal-Mounted Eyewashes</b>		
Eyewash, plastic bowl	S19-210	S19214EW
Eyewash, stainless steel bowl	S19-210B	S19214B
<b>Pedestal-Mounted Eyewashes with Hinged Dust Cover</b>		
Eyewash, plastic bowl w/ dust cover	N/A	S19214PDC
Eyewash, stainless steel bowl & hinged dust cover	S19-210DC	S19214DC
<b>Pedestal-mounted Eye/Face Washes</b>		
Eye/face wash, plastic bowl	S19-210FW	S19214FW
Eye/face wash, stainless steel bowl	S19-210Y	S19214Y
Eye/face wash, stainless steel bowl w/spray ring & 8' (2.4 m) hand-held drench hose	S19-210P	S19214P
Eye/face wash, stainless steel bowl, hand/foot operated	S19-210YF	S19214YF
<b>Barrier-Free, Pedestal-Mounted Eye/Face Washes</b>		
Eye/face wash, barrier-free, stainless steel bowl	S19-210BF	S19214Y
<b>Pedestal-Mounted Eye/Face Washes with Hinged Dust Cover</b>		
Eye/face wash, plastic bowl w/ dust cover	N/A	S19214PDCFW
Eye/face wash, stainless steel bowl & hinged dust cover	S19-210DCFW	S19214DCFW
<b>Chrome-Plated Brass Finish Pedestal-Mounted Eyewashes</b>		
Eyewash, chrome-plated brass piping & stainless steel bowl	S19-210U	
<b>All Stainless Steel Pedestal-Mounted Eyewashes and Eye/Face Washes</b>		
Eyewash, all stainless steel, corrosion-resistant	S19-210BSS	S19214BSS
Eyewash, all stainless steel with hinged dust cover	S19-210SC	S19214SC
Eye/face wash w/spray ring; all stainless steel, corrosion-resistant, hand/foot operated	S19-210SS	S19214SS
<b>Wall-Mounted Eyewashes</b>		
Eyewash, plastic bowl	S19-220	S19224EW
Eyewash, plastic bowl, w/tailpiece & P-trap	S19-220PT	S19224PT
Eyewash, stainless steel bowl	S19-220B	S19224B
Eyewash, stainless steel bowl, with tailpiece & P-trap	S19-220BPT	S19224BPT
<b>Wall-Mounted Eyewashes with Hinged Dust Cover</b>		
Eyewash, plastic bowl w/ dust cover	N/A	S19224PDC
Eyewash, stainless steel bowl & hinged dust cover	S19-220DC	S19224DC
Eyewash, stainless steel bowl & hinged dust cover, w/tailpiece & P-trap	S19-220DCPT	S19224DCPT
<b>Wall-Mounted Eye/Face Washes</b>		
Eye/face wash, plastic bowl	S19-220FW	S19224FW
Eye/face wash, plastic bowl, w/tailpiece & P-trap	S19-220FWPT	S19224FWPT
Eye/face wash, stainless steel bowl	S19-220T	S19224T
Eye/face wash w/spray ring, stainless steel bowl, 8' (2.4 m) hand-held drench hose	S19-220P	S19224P
Eye/face wash, stainless steel bowl, w/tailpiece & P-trap	S19-220TPT	S19224TPT
Eye/face wash w/spray ring, stainless steel bowl, hand/foot operated	S19-220Y	S19224Y
<b>Wall-Mounted Eye/Face Washes with Hinged Dust Cover</b>		
Eye/face wash, plastic bowl w/ dust cover	N/A	S19224PDCFW
Eye/face wash, stainless steel bowl & hinged dust cover	S19-220DCFW	S19224DCFW
Eye/face wash, stainless steel bowl & hinged dust cover, w/spray ring	S19-220DCR	S19224DCFW
Eye/face wash, stainless steel bowl & hinged dust cover, w/spray ring, tailpiece & P-trap	S19-220DCRPT	S19224DCRPT



Product	Classic Model No.	New Halo No.
<b>Barrier-Free, Wall-Mounted Eyewashes</b>		
Eyewash, barrier-free, plastic bowl (no wrap-around skirt)	S19-220ABF	N/A
Eyewash, barrier-free, stainless steel bowl (no wrap-around skirt)	S19-220BBF	N/A
<b>Barrier-Free, Wall-Mounted Eye/Face Wash with Wrap-Around Skirt</b>		
Eye/face wash w/spray ring, barrier-free, stainless steel bowl & wrap-around skirt	S19-220BF	N/A
<b>All Stainless Steel Wall-Mounted Eyewashes and Eye/Face Washes</b>		
Eyewash, all stainless steel, w/hinged dust cover	S19-220SC	S19224SC
Eye/face wash w/spray ring, all stainless steel	S19-220SS	S19224SS
Eye/face wash, all stainless steel except ABS plastic sprayheads	S19-220TSS	
<b>Combination Drench Showers and Eyewash Units</b>		
Eyewash; plastic showerhead & bowl	S19-310	S19314EW
Eyewash; plastic showerhead & bowl w/hose spray	S19-310P	S19314P
Eyewash; plastic showerhead, stainless steel bowl	S19-310SB	S19314SB
Eyewash; stainless steel bowl, hand/foot operated Eyewash, plastic showerhead	S19-310LL	S19314LL
Eyewash; stainless steel bowl & showerhead	S19-310F	S19314F
Eyewash; stainless steel showerhead & bowl, hand/foot operated Eyewash	S19-310UU	S19314UU
<b>Combination Drench Showers and Eyewash Units with Hinged Dust Cover</b>		
Eyewash; plastic showerhead & bowl w/ dust cover	N/A	S19314PDC
Eyewash; stainless steel bowl & hinged dust cover, plastic showerhead	S19-310DC	S19314DC
<b>Combination Drench Showers and Eye/Face Wash Units</b>		
Eye/face wash; plastic bowl & showerhead	S19-310FW	S19314FW
Eye/face wash; stainless steel bowl, plastic showerhead	S19-310SBFW	S19314SBFW
Eye/face wash; stainless steel bowl, plastic showerhead, hand/foot operated	S19-310AC	S19314AC
Eye/face wash; stainless steel showerhead & bowl	S19-310TT	S19314TT
Eye/face wash w/spray ring; stainless steel showerhead & bowl; hand/foot operated	S19-310SPR	S19314SPR
Eye/face wash w/spray ring; barrier-free, plastic bowl, plastic showerhead	S19-310BFPB	S19314BFPB
Eye/face wash w/spray ring; barrier-free, stainless steel bowl, plastic showerhead	S19-310BF	S19314BF
<b>Combination Drench Showers and Eye/Face Wash Units with Hinged Dust Cover</b>		
Eye/face wash; plastic showerhead & bowl w/ dust cover	N/A	S19314PDCFW
Eye/face wash; stainless steel bowl & hinged dust cover, plastic showerhead	S19-310DCFW	S19314DCFW
Eye/face wash; barrier-free, stainless steel bowl & hinged dust cover, plastic showerhead	S19-310DCBF	S19314DCBF
<b>Combination Drench Showers and Eye/Face Wash Unit without Eyewash Bowl</b>		
Eye/face wash; plastic showerhead (no bowl)	S19-310GG	S19314GG
<b>All Stainless Steel Combination Drench Showers and Eyewash Units or Eye/Face Wash Units</b>		
Eye/face wash w/spray ring, barrier-free, all stainless steel	S19-310BFSS	S19-314BFSS
Eyewash; all stainless steel, corrosion-resistant	S19-310FSS	S19-314FSS
Eyewash; chrome-plated red brass pipe & fittings, stainless steel bowl & showerhead	S19-310JJ	
Eyewash; all stainless steel w/hinged dust cover	S19-310SC	S19314SC
Eye/face wash w/spray ring; type 304 all stainless steel, hand/foot operated	S19-310SS	S19314SS
Eyewash; type 316 all stainless steel, hand/foot operated	S19-310SS16	S19314SS16



# Halo S19214 & S19224 Series Certification Reference

Halo Model No.	Description	UL certified to ANSI/ISEA	Intertek certified to EN standards	IAPMO Oceana certified to AS4775 & AS4020
Eyewashes				
S19214EW	Halo Eyewash, plastic bowl	•	•	
S19214EWZ	Halo Eyewash, plastic bowl		•	
S19214EWZS	Halo Eyewash, plastic bowl		•	•
S19214B	Halo Eyewash, stainless steel bowl	•	•	
S19214BZ	Halo Eyewash, stainless steel bowl		•	
S19214BZS	Halo Eyewash, stainless steel bowl		•	•
S19224EW	Halo Eyewash, plastic bowl	•	•	
S19224EWZ	Halo Eyewash, plastic bowl		•	
S19224EWZS	Halo Eyewash, plastic bowl		•	•
S19224PT	Halo Eyewash, plastic bowl, p-trap	•	•	
S19224PTZ	Halo Eyewash, plastic bowl, p-trap		•	
S19224PTZS	Halo Eyewash, plastic bowl, p-trap		•	
S19224B	Halo Eyewash, stainless steel bowl	•	•	
S19224BZ	Halo Eyewash, stainless steel bowl		•	
S19224BZS	Halo Eyewash, stainless steel bowl		•	•
S19224BPT	Halo Eyewash, stainless steel bowl, p-trap	•	•	
S19224BPTZ	Halo Eyewash, stainless steel bowl, p-trap		•	
S19224BPTZS	Halo Eyewash, stainless steel bowl, p-trap		•	
Eyewashes with Dust Cover				
S19214PDC	Halo Eyewash, plastic bowl w/ dust cover	•	•	
S19214PDCZ	Halo Eyewash, plastic bowl w/ dust cover		•	
S19214PDCZS	Halo Eyewash, plastic bowl w/ dust cover		•	•
S19214DC	Halo Eyewash, stainless steel bowl & hinged dust cover	•	•	
S19214DCZ	Halo Eyewash, stainless steel bowl & hinged dust cover		•	
S19214DCZS	Halo Eyewash, stainless steel bowl & hinged dust cover		•	•
S19224PDC	Halo Eyewash, plastic bowl w/ dust cover	•	•	
S19224PDCZ	Halo Eyewash, plastic bowl w/ dust cover		•	
S19224PDCZS	Halo Eyewash, plastic bowl w/ dust cover		•	•
S19224DC	Halo Eyewash, stainless steel bowl & hinged dust cover	•	•	
S19224DCZ	Halo Eyewash, stainless steel bowl & hinged dust cover		•	
S19224DCZS	Halo Eyewash, stainless steel bowl & hinged dust cover		•	•
S19224DCPT	Halo Eyewash, stainless steel bowl & hinged dust cover, p-trap	•	•	
S19224DCPTZ	Halo Eyewash, stainless steel bowl & hinged dust cover, p-trap		•	
S19224DCPTZS	Halo Eyewash, stainless steel bowl & hinged dust cover, p-trap		•	
Eye-Face Washes				
S19214FW	Halo Eye/face wash, plastic bowl	•	•	
S19214FWZ	Halo Eye/face wash, plastic bowl		•	
S19214FWZS	Halo Eye/face wash, plastic bowl		•	•
S19214P	Halo Eye/face wash, stainless steel bowl w/ hose spray	•	•	
S19214PZ	Halo Eye/face wash, stainless steel bowl w/ hose spray		•	
S19214Y	Halo Eye/face wash, stainless steel bowl	•	•	
S19214YZ	Halo Eye/face wash, stainless steel bowl		•	
S19214YZS	Halo Eye/face wash, stainless steel bowl		•	•
S19214YF	Halo Eye/face wash, stainless steel bowl, hand/foot operated	•	•	
S19214YFZ	Halo Eye/face wash, stainless steel bowl, hand/foot operated		•	



Halo Model No.	Description	UL certified to ANSI/ISEA	Intertek certified to EN standards	IAPMO Oceana certified to AS4775 & AS4020
Eye-Face Washes				
S19214YFZS	Halo Eye/face wash, stainless steel bowl, hand/foot operated		•	•
S19224FW	Halo Eye/face wash, plastic bowl	•	•	
S19224FWZ	Halo Eye/face wash, plastic bowl		•	
S19224FWZS	Halo Eye/face wash, plastic bowl		•	•
S19224FWPT	Halo Eye/face wash, plastic bowl, p-trap	•	•	
S19224FWPTZ	Halo Eye/face wash, plastic bowl, p-trap		•	
S19224FWPTZS	Halo Eye/face wash, plastic bowl, p-trap		•	
S19224T	Halo Eye/face wash, stainless steel bowl	•	•	
S19224TZ	Halo Eye/face wash, stainless steel bowl		•	
S19224TZS	Halo Eye/face wash, stainless steel bowl		•	•
S19224P	Halo Eye/face wash, stainless steel bowl w/ hose spray, tailpiece	•	•	
S19224PZ	Halo Eye/face wash, stainless steel bowl w/ hose spray, tailpiece		•	
S19224TPT	Halo Eye/face wash, stainless steel bowl, p-trap	•	•	
S19224TPTZ	Halo Eye/face wash, stainless steel bowl, p-trap		•	
S19224TPTZS	Halo Eye/face wash, stainless steel bowl, p-trap		•	
S19224Y	Halo Eye/face wash, stainless steel bowl, hand/foot operated, tailpiece	•	•	
S19224YZ	Halo Eye/face wash, stainless steel bowl, hand/foot operated, tailpiece		•	
S19224YZS	Halo Eye/face wash, stainless steel bowl, hand/foot operated, tailpiece		•	•
Eye-Face Washes with Dust covers				
S19214PDCFW	Halo Eye/face wash, plastic bowl w/ dust cover	•	•	
S19214PDCFWZ	Halo Eye/face wash, plastic bowl w/ dust cover		•	
S19214PDCFWZS	Halo Eye/face wash, plastic bowl w/ dust cover		•	•
S19214DCFW	Halo Eye/face wash, stainless steel bowl & hinged dust cover	•	•	
S19214DCFWZ	Halo Eye/face wash, stainless steel bowl & hinged dust cover		•	
S19214DCFWZS	Halo Eye/face wash, stainless steel bowl & hinged dust cover		•	•
S19224PDCFW	Halo Eye/face wash, plastic bowl w/ dust cover	•	•	
S19224PDCFWZ	Halo Eye/face wash, plastic bowl w/ dust cover		•	
S19224PDCFWZS	Halo Eye/face wash, plastic bowl w/ dust cover		•	•
S19224DCFW	Halo Eye/face wash, stainless steel bowl & hinged dust cover	•	•	
S19224DCFWZ	Halo Eye/face wash, stainless steel bowl & hinged dust cover		•	
S19224DCFWZS	Halo Eye/face wash, stainless steel bowl & hinged dust cover		•	•
S19224DCRPT	Halo Eye/face wash, stainless steel bowl & hinged dust cover, p-trap	•	•	
S19224DCRPTZ	Halo Eye/face wash, stainless steel bowl & hinged dust cover, p-trap		•	
S19224DCRPTZS	Halo Eye/face wash, stainless steel bowl & hinged dust cover, p-trap		•	
All Stainless Steel Eye/Face Wash				
S19214BSS	Halo stainless steel eye/face wash and bowl	•	•	
S19214BSSZ	Halo stainless steel eye/face wash and bowl		•	•
S19214SC	Halo stainless steel eye/face wash, bowl and cover	•	•	
S19214SCZ	Halo stainless steel eye/face wash, bowl and cover		•	•
S19214SS	Halo stainless steel eye/face wash and bowl with foot activation	•	•	
S19214SSZ	Halo stainless steel eye/face wash and bowl with foot activation		•	•
S19224SC	Halo stainless steel eye/face wash, bowl and cover	•	•	
S19224SCZ	Halo stainless steel eye/face wash, bowl and cover		•	•
S19224SS	Halo stainless steel eye/face wash and bowl	•	•	
S19224SSZ	Halo stainless steel eye/face wash and bowl		•	•



# Halo S19314 Series Certification Reference

Halo Model No.	Description	UL certified to ANSI/ISEA	Intertek certified to EN standards	IAPMO Oceana certified to AS4775 & AS4020
Eyewashes				
S19314EW	Halo Eyewash, plastic showerhead & bowl	•	•	
S19314EWZ	Halo Eyewash, plastic showerhead & bowl		•	
S19314EWZS	Halo Eyewash, plastic showerhead & bowl		•	•
S19314P	Halo Eyewash, plastic showerhead & bowl w/ hose spray	•	•	
S19314PZ	Halo Eyewash, plastic showerhead & bowl w/ hose spray		•	
S19314SB	Halo Eyewash, plastic showerhead, stainless steel bowl	•	•	
S19314SBZ	Halo Eyewash, plastic showerhead, stainless steel bowl		•	
S19314SBZS	Halo Eyewash, plastic showerhead, stainless steel bowl		•	•
S19314LL	Halo Eyewash, plastic showerhead, stainless steel bowl, hand/foot activated	•	•	
S19314LLZ	Halo Eyewash, plastic showerhead, stainless steel bowl, hand/foot activated		•	
S19314LLZS	Halo Eyewash, plastic showerhead, stainless steel bowl, hand/foot activated		•	•
S19314F	Halo Eyewash, plastic showerhead w/ stainless steel shroud & bowl	•	•	
S19314FZ	Halo Eyewash, plastic showerhead w/ stainless steel shroud & bowl		•	
S19314FZS	Halo Eyewash, plastic showerhead w/ stainless steel shroud & bowl		•	•
S19314UU	Halo Eyewash, plastic showerhead w/ stainless steel shroud & bowl, hand/foot operated Eyewash	•	•	
S19314UUZ	Halo Eyewash, plastic showerhead w/ stainless steel shroud & bowl, hand/foot operated Eyewash		•	
S19314UUZS	Halo Eyewash, plastic showerhead w/ stainless steel shroud & bowl, hand/foot operated Eyewash		•	•
Eyewashes with Dust Cover				
S19314PDC	Halo Eyewash, plastic showerhead & bowl w/ dust cover	•	•	
S19314PDCZ	Halo Eyewash, plastic showerhead & bowl w/ dust cover		•	
S19314PDCZS	Halo Eyewash, plastic showerhead & bowl w/ dust cover		•	•
S19314DC	Halo Eyewash, plastic showerhead, stainless steel bowl & hinged dust cover	•	•	
S19314DCZ	Halo Eyewash, plastic showerhead, stainless steel bowl & hinged dust cover		•	
S19314DCZS	Halo Eyewash, plastic showerhead, stainless steel bowl & hinged dust cover		•	•
Eye-Face Washes				
S19314FW	Halo Eye/face wash, plastic showerhead & bowl	•	•	
S19314FWZ	Halo Eye/face wash, plastic showerhead & bowl		•	
S19314FWZS	Halo Eye/face wash, plastic showerhead & bowl			•
S19314SBFW	Halo Eye/face wash, plastic showerhead, stainless steel bowl	•	•	
S19314SBFWZ	Halo Eye/face wash, plastic showerhead, stainless steel bowl		•	
S19314SBFWZS	Halo Eye/face wash, plastic showerhead, stainless steel bowl		•	•
S19314AC	Halo Eye/face wash, plastic showerhead, stainless steel bowl, hand/foot operated Eyewash	•	•	
S19314ACZ	Halo Eye/face wash, plastic showerhead, stainless steel bowl, hand/foot operated Eyewash		•	
S19314ACZS	Halo Eye/face wash, plastic showerhead, stainless steel bowl, hand/foot operated Eyewash		•	•
S19314TT	Halo Eye/face wash, plastic showerhead w/ stainless steel shroud & bowl	•	•	



Halo Model No.	Description	UL certified to ANSI/ISEA	Intertek certified to EN standards	IAPMO Oceana certified to AS4775 & AS4020
Eye-Face Washes				
S19314TTZ	Halo Eye/face wash, plastic showerhead w/ stainless steel shroud & bowl		•	
S19314TTZS	Halo Eye/face wash, plastic showerhead w/ stainless steel shroud & bowl		•	•
S19314SPR	Halo Eye/face wash, stainless steel showerhead & bowl, hand/foot operated Eyewash	•	•	
S19314SPRZ	Halo Eye/face wash, stainless steel showerhead & bowl, hand/foot operated Eyewash		•	
S19314SPRZS	Halo Eye/face wash, stainless steel showerhead & bowl, hand/foot operated Eyewash		•	•
S19314BFPB	Halo Eye/face wash, barrier-free, plastic showerhead & bowl	•	•	
S19314BFPBZ	Halo Eye/face wash, barrier-free, plastic showerhead & bowl		•	
S19314BFPBZS	Halo Eye/face wash, barrier-free, plastic showerhead & bowl		•	•
S19314BF	Halo Eye/face wash, barrier-free, plastic showerhead, stainless steel bowl	•	•	
S19314BFZ	Halo Eye/face wash, barrier-free, plastic showerhead, stainless steel bowl		•	
S19314BFZS	Halo Eye/face wash, barrier-free, plastic showerhead, stainless steel bowl		•	•
Eye-Face Washes with Dust covers				
S19314PDCFW	Halo Eye/face wash, plastic showerhead & bowl w/ dust cover	•	•	
S19314PDCFWZ	Halo Eye/face wash, plastic showerhead & bowl w/ dust cover		•	
S19314PDCFWZS	Halo Eye/face wash, plastic showerhead & bowl w/ dust cover		•	•
S19314DCFW	Halo Eye/face wash, plastic showerhead, stainless steel bowl & hinged dust cover	•	•	
S19314DCFWZ	Halo Eye/face wash, plastic showerhead, stainless steel bowl & hinged dust cover		•	
S19314DCFWZS	Halo Eye/face wash, plastic showerhead, stainless steel bowl & hinged dust cover		•	•
S19314DCBF	Halo Eye/face wash, barrier-free, plastic showerhead, stainless steel bowl w/ dust cover	•	•	
S19314DCBFZ	Halo Eye/face wash, barrier-free, plastic showerhead, stainless steel bowl w/ dust cover		•	
S19314DCBFZS	Halo Eye/face wash, barrier-free, plastic showerhead, stainless steel bowl w/ dust cover		•	•
Eye-Face Washes without Eyewash Bowl				
S19314GG	Halo Eye/face wash, plastic showerhead, no bowl	•	•	
S19314GGZ	Halo Eye/face wash, plastic showerhead, no bowl		•	
S19314GGZS	Halo Eye/face wash, plastic showerhead, no bowl		•	•
All Stainless Steel Eye/Face Wash				
S19314BFSS	Halo stainless steel eye/face wash and showerhead, barrier free	•	•	
S19314BFSSZ	Halo stainless steel eye/face wash and showerhead, barrier free		•	•
S19314FSS	Halo stainless steel eye/face wash and showerhead	•	•	
S19314FSSZ	Halo stainless steel eye/face wash and showerhead		•	•
S19314SC	Halo stainless steel eye/face wash and bowl, cover and showerhead	•	•	
S19314SCZ	Halo stainless steel eye/face wash and bowl, cover and showerhead		•	•
S19314SS	Halo stainless steel eye/face wash and showerhead with foot activation	•	•	
S19314SSZ	Halo stainless steel eye/face wash and showerhead with foot activation		•	•
S19314SS16	Halo 316 stainless steel eye/face wash and showerhead with foot activation	•	•	
S19314SS16Z	Halo 316 stainless steel eye/face wash and showerhead with foot activation		•	•



# Numerical Index

MODEL NO.	PG	MODEL NO.	PG	MODEL NO.	PG	MODEL NO.	PG	MODEL NO.	PG
<b>Fixtures</b>		SI9214BZ	17	SI9224DCFW	28	SI9-240	68	SI9314ACZ	37
Keltech CLE Series	53	SI9214BZS	17	SI9224DCFWZ	28	SI9-240FW	68	SI9314ACZS	38
Keltech SNA Series	53	SI9214DC	18	SI9224DCFWZS	28	SI9-260	68	SI9314BF	39
Keltech SI9361	53	SI9214DCZ	18	SI9224DCPT	26	SI9-270B	68	SI9314BFZ	39
Keltech SI9361HF	53	SI9214DCZS	18	SI9224DCPTZ	26	SI9-270BL	68	SI9314BFZS	40
SI9-110	10	SI9214DCFW	19	SI9224DCPTZS	26	SI9-270C	71	SI9314BFPB	39
SI9-110BF	10	SI9214DCFWZ	19	SI9224DCRPT	28	SI9-270E	72	SI9314BFPBZ	39
SI9-110BFSS	10	SI9214DCFWZS	20	SI9224DCRPTZ	28	SI9-270HD	71	SI9314BFPBZS	39
SI9-110BFSSZ	10	SI9214EW	17	SI9224DCRPTZS	29	SI9-270HW	71	SI9314BFSS	42
SI9-110SS	10	SI9214EWZ	17	SI9224EW	24	SI9-270JD	72	SI9314BFSSZ	42
SI9-110SSZ	10	SI9214EWZS	17	SI9224EWZ	24	SI9-270JW	72	SI9314DC	36
SI9-120	12	SI9214FW	18	SI9224EWZS	24	SI9274C	71	SI9314DCZ	36
SI9-120A	12	SI9214FWZ	18	SI9224FW	26	SI9274E	72	SI9314DCZS	36
SI9-120ABF	13	SI9214FWZS	18	SI9224FWZ	26	SI9274HD	71	SI9314DCBF	41
SI9-120BF	13	SI9214P	19	SI9224FWZS	26	SI9274HDR	71	SI9314DCBFZ	41
SI9-120FM	13	SI9214PZ	19	SI9224FWPT	26	SI9274HDB	71	SI9314DCBFZS	41
SI9-120FMBF	13	SI9214PDC	17	SI9224FWPTZ	26	SI9274HW	71	SI9314DCFW	40
SI9-120G	12	SI9214PDCZ	17	SI9224FWPTZS	26	SI9274HWP	71	SI9314DCFWZ	40
SI9-120HFP	12	SI9214PDCZS	17	SI9224P	27	SI9274JD	72	SI9314DCFWZS	40
SI9-120P	12	SI9214PDCFW	19	SI9224PZ	27	SI9274JDB	72	SI9314EW	34
SI9-120SS	12	SI9214PDCFWZ	19	SI9224PDC	25	SI9274JW	72	SI9314EWZ	34
SI9-120SSZ	12	SI9214PDCFWZS	19	SI9224PDCZ	25	SI9274JWB	72	SI9314EWZS	34
SI9-120SSBF	13	SI9214SC	20	SI9224PDCZS	25	SI9-280D	71	SI9314F	35
SI9-120SSBFZ	13	SI9214SCZ	20	SI9224PDCFW	28	SI9-280W	71	SI9314FZ	35
SI9-120T	12	SI9214SS	20	SI9224PDCFWZ	28	SI9284H	75	SI9314FZS	35
SI9-125BF	74	SI9214SSZ	20	SI9224PDCFWZS	28	SI9284HB	75	SI9314FW	36
SI9-125FMBF	74	SI9214Y	18	SI9224PT	24	SI9284J	75	SI9314FWZ	37
SI9-125SBF	74	SI9214YZ	18	SI9224PTZ	24	SI9284JB	75	SI9314FWZS	37
SI9-125SFMBF	74	SI9214YZS	18	SI9224PTZS	24	SI9-290D	72	SI9314FSS	42
SI9-130	13	SI9214YF	18	SI9224SC	29	SI9-290W	72	SI9314FSSZ	42
SI9-130A	13	SI9214YFZ	19	SI9224SCZ	29	SI9294HB	76	SI9314GG	41
SI9-130ABF	14	SI9214YFZS	19	SI9224SS	29	SI9294HBT	76	SI9314GGZ	41
SI9-130BF	14	SI9-2150	55	SI9224SSZ	29	SI9294JB	76	SI9314GGZS	41
SI9-130F	14	SI9-2200	55	SI9224T	26	SI9294JBT	76	SI9314LL	35
SI9-130SS	13	SI9-220BF	29	SI9224TZ	27	SI9-304D2B	47	SI9314LLZ	35
SI9-130SSZ	13	SI9-220HFP	29	SI9224TZS	27	SI9-304D2BL	47	SI9314LLZS	35
SI9-130SSBF	14	SI9224B	24	SI9224TPT	27	SI9-304D2T	47	SI9314P	34
SI9-130SSBFZ	14	SI9224BZ	24	SI9224TPTZ	27	SI9-304D2TL	47	SI9314PZ	34
SI9-2000	55	SI9224BZS	24	SI9224TPTZS	27	SI9-304GAB	47	SI9314PDC	36
SI9-2000EFX	55	SI9224BPT	25	SI9224Y	27	SI9-304GABL	47	SI9314PDCZ	36
SI9-200B	68	SI9224BPTZ	25	SI9224YZ	27	SI9-304GAT	47	SI9314PDCZS	36
SI9-2100	55	SI9224BPTZS	25	SI9224YZS	28	SI9-304GATL	47	SI9314PDCFW	40
SI9214BSS	20	SI9224DC	25	SI9-2250	55	SI9-310PVC	43	SI9314PDCFWZ	40
SI9214BSSZ	20	SI9224DCZ	25	SI9-2300	55	SI9-310TW	42	SI9314PDCFWZS	40
SI9214B	17	SI9224DCZS	25	SI9-2350	55	SI9314AC	37	SI9314SB	34



MODEL NO.	PG	MODEL NO.	PG	MODEL NO.	PG	MODEL NO.	PG	MODEL NO.	PG
SI9314SBZ	34	SI9374	50	SI9-324EG	86	204-421	94	S39-395	95
SI9314SBZS	34	SI9378	50	SI9-32EGW	86	269-053	92	S39-396	88
SI9314SBFW	37	SI9382	50	SI9-330	84	269-054	92	S39-397	88
SI9314SBFWZ	37	SI9384	50	SI9-330ST	84	269-1379	81, 94	S39-681	88
SI9314SBFWZS	37	SI9387	50	SI9-399	84	269-1444	94	S39-682	88
SI9314SC	42	SI9388	50	SI9-430EH	84	269-964	94	S39-817	92
SI9314SCZ	42	SI9-399	81	SI9-430SH	84	S05-127	88	S45-122	87
SI9314SPR	38	SI9-430A	65	SI9-671HR	84	S05-190	90	S45-123	87
SI9314SPRZ	38	SI9-430D	65	SI9-690A	84	S05-192	90	S45-1314SS	95
SI9314SPRZS	39	SI9-430EH	65	SI9-690HR	84	S05-204	90	S45-1314SS16	95
SI9314SS	43	SI9-430SH	65	SI9-788HR	84	S05-205	90	S45-1986	86
SI9314SSZ	43	SI944011ABC	66	SI9-921HR	84	S08-336	87	S45-1987	86
SI9314SS16	43	SI944011BBC	66	S45-1964	91	S08-338	87	S45-1989	86
SI9314SS16Z	43	SI944011CBC	66	S45-2396	91	S08-390	90	S45-1990	86
SI9314TT	38	SI944011CBD	66	Replacement Parts		SI9-0011	92	S45-2309	66, 93
SI9314TTZ	38	SI944022ABC	66	107-371	88	SI9-949	94	S45-2310	66, 93
SI9314TTZS	38	SI9-460	65	113-1150	89	S21-071	89	S45-2453	88
SI9314UU	35	SI9-460EFW	65	113-1151	89	S21-072	89	S45-2675	90
SI9314UUZ	35	SI9-465	65	113-1159	89	S21-073	89	S45-2676	90
SI9314UUZS	36	SI9-465EFW	65	113-1185	89	S21-074	89	S45-572	95
SI9-319B2	59	SI9-670	83	114-050	94	S21-075	89	S45-620	95
SI9-319B4	59	SI9-671	83	114-050E	94	S24-192	92	S53-063	88
SI9-319S2	59	SI9-671H	83	114-051	94	S24-193	92	S53-310	88
SI9-319S4	59	SI9-672	83	114-051E	94	S24-194	92	S65-339	90
SI9-322D	57	SI9-690	83	114-052	94	S24-195	92	S88-068	90
SI9-322E	57	SI9-690H	83	114-052E	94	S24-196	92	S89-002	92
SI9-323D	57	SI9-690LHS	83	125-032	89	S24-200	92	S89-003	92
SI9-323E	57	SI9-788	83	125-167	89	S24-202	92	S90-388	90
SI9-324D	58	SI9-788H	83	128-135	87	S27-265	93	S90-390	90
SI9-324E	58	SI9-788LHS	83	128-156A	91	S27-276	92	S90-391	90
SI9-324DG	58	SI9-921	81	128-156B	91	S27-278	92	S90-392	90
SI9-324EG	58	SI9-921H	81	128-156C	91	S27-282	88		
SI9-324DGW	58	SI9-921HR	81	128-156D	91	S27-287	88		
SI9-324EGW	58	SI9-949	81	128-156E	91	S27-303	66, 93		
SI9-324D2D	58	Accessories		128-156F	91	S27-327	90		
SI9-324D1D	58	SI9-322D	85	128-156G	91	S27-328	90		
SI9345HFB	77	SI9-322E	85	133-140	81, 94	S30-059	92		
SI9345HFBT	77	SI9-323D	85	140-226	66, 93	S30-061	92		
SI9345HXB	77	SI9-323E	85	153-395	95	S30-070	87		
SI9345HXB T	77	SI9-324D	85	153-396	95	S30-071	87		
SI9345JFB	77	SI9-324D1D	86	153-401	95	S30-072	87		
SI9345JFBT	77	SI9-324D2D	86	154-058	89	S30-074	87		
SI9345JXB	77	SI9-324DG	85	154-147	92	S30-075	87		
SI9345JXB T	77	SI9-324DGW	85	187-053	89	S30-087	87		
SI9372	50	SI9-324E	85	187-320	90	S39-394	88		





## Complimentary & Confidential Evaluation

We offer a confidential no-charge evaluation of your workspaces to assess your current situation and suggest a plan for your emergency equipment needs.

262 251 6000  
800 BRADLEY [bradleycorp.com](http://bradleycorp.com)  
W142 N9101 Fountain Boulevard  
Menomonee Falls, WI 53051 USA  
3928-7.5-0218

